



PX1

For Product information
visit: www.COASTportland.com

商品の仕様はCOASTのウェブサイト
(www.COASTportland.com)
をご覧ください。

PX1 INSTRUCTIONS:

BATTERY INSTALLATION:

Turn the end cap in a counterclockwise direction to remove the cap. Remove the battery cartridge.

Place three AAA batteries into the cartridge in the direction indicated on the cartridge.

Replace the cartridge in the light with the red end going in first. Replace the tail cap and turn it clockwise to tighten it until it is completely closed.

QUICK CYCLE SWITCH OPERATION:

This flashlight is equipped with COAST's Quick-Cycle Switch, featuring high and low beams. To activate the high beam from the off position, press the on/off switch until it clicks once, then releases. Press the on/off switch until it clicks a second time to turn off the light. To activate the low mode, press the on/off switch a third time until it clicks. Press the on/off switch until it clicks a fourth time to turn off the light.

The light can also be operated in "momentary" mode. Momentary mode is activated by partially depressing the on/off switch (less pressure than required for a full click). The momentary switch will cycle the light through the high and low beam modes.

Any time the light is turned off for more than five seconds, the high/low cycle will reset, and the high beam will be activated when the light is turned on again.

PURE BEAM FOCUSING OPTIC with Twist Focus:

This flashlight is equipped with COAST's Pure Beam Focusing Optic with Twist Focus that allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot beam for long distance illumination.

To adjust the beam into the Bulls-Eye Spot mode, twist the head of the light counter clockwise.

To change the beam into the flood light mode, twist the head of the light clockwise.

MAINTENANCE:

Wipe the external body with a cloth moistened with water or isopropyl alcohol. Do not submerge.

PX1 使用ガイド:

電池の取り付け:

後部キャップを反時計方向に回して取り外し、バッテリーカートリッジを取り出します。

カートリッジ上の矢印が示す方向に従って、カートリッジに3本の単4形乾電池を挿入します。

懐中電灯内のカートリッジを戻します。この際に、赤い方の端を先に差し込みます。後部キャップを戻し、完全に締まるまで時計回りに回します。

「クイック・サイクル・スイッチ」の操作:

このフラッシュライトでは、ハイビームとロービームを切り替えることができる。COAST独自の「クイック・サイクル・スイッチ」を装備しています。OFFの状態からハイビームをONにするには、ON/OFFスイッチを1度だけカチッとするまで押します。ライトをOFFにするには、ON/OFFスイッチを2度目にカチッとするまで押します。ロービームをONにするには、ON/OFFスイッチを3度目にカチッとするまで押して指を離します。ライトをOFFにするには、ON/OFFスイッチを4度目にカチッとするまで押します。

ライトを「半押し」モードで点灯させることもできます。「半押し」モードでは、ON/OFFスイッチを半押し（カチッとする手前で止めた）状態で使用します。このモードでスイッチを動作させると、ハイビームとロービームが交互に切り替わります。

ライトを5秒以上OFFにすると、ハイビームとロービームの切替サイクルがリセットされます。その後再びONにすると、最初はハイビームがONになります。

ツイスト式ビュア・ビーム範囲調節システム:

このフラッシュライトは、COASTの「ツイスト式ビュア・ビーム範囲調節システム」を備えています。この機構により、広範囲を照射するビームと、範囲を絞ることで長距離まで届く「ブルズアイ・スポット・ビーム」を切り替えることができます。

ビームを「ブルズアイ・スポット・ビーム」に切り替えるには、ライトの先端部分を反時計方向に回します。

ビームの照射範囲を広くするには、ライトの先端部分を時計回りに回転させます。

メンテナンス:

水またはイソプロピルアルコールで濡らせた布で、本体の外部を拭いてください。絶対に水に浸けしないでください。

警告

- 光をのぞきこんだり、ほかの人の目に当てたりしない。
- 本品は水中用ではないので、水中で使用しない。
- 電池蓋は必ずしっかりと閉じる。閉じていないと防水性能が損なわれます。
- 本品に衝撃を与えたり、無理な力を加えない。
- 本品を分解したり改造したりしない。
- 古い乾電池と新しい乾電池、または異種の乾電池を同時に使用しない。
- 乾電池の発熱・破裂・液もれの原因となります。
- 電池交換の際は、全本数同時に交換する。

注意

- LEDの特性上、光の色や明るさにバラつきが出る場合がありますので、ご了承ください。
- LEDは交換できません。
- 以下のことを守らないと、電池の液漏れなどの原因となります。
 - 電池の仕様表示に従って正しく使用する。 ○ 乾電池は必ず⊕⊖を本品に正しく使用する。 ○ 定期的に点灯、点検をする。 ○ 使い切った乾電池はすぐに電池ボックスから取り出す。 ○ 電池の容量が少なくなると、LED球にチラツキがでます。電池をお取替えください。 ○ オキシライド系乾電池のように初期電圧の高い電池のご使用はお避け下さい。故障の原因となります。(オキシライドはバナソニック製の登録商標です。)