

互換電池型番対応表




◎OHM 2019年製		◎OHM 2015年製		◎OHM 2008年製		パナソニック
長持ちタイプ	高容量タイプ	長持ちタイプ	高容量タイプ	長持ちタイプ	高容量タイプ	
	TEL-B71	TEL-B0001H		TEL-B2001H		BK-T201
TEL-B22	TEL-B72	TEL-B0002H	TEL-B0052H	TEL-B2011H	TEL-B2061H	BK-T312
TEL-B23	TEL-B73	TEL-B0003H	TEL-B0053H	TEL-B2012H	TEL-B2062H	BK-T313
TEL-B24	TEL-B74	TEL-B0004H	TEL-B0054H	TEL-B2014H	TEL-B2064H	BK-T315
TEL-B25	TEL-B75	TEL-B0005H	TEL-B0055H	TEL-B2015H	TEL-B2065H	BK-T316
TEL-B26	TEL-B76	TEL-B0006H		TEL-B2016H	TEL-B2066H	BK-T317
TEL-B27	TEL-B77	TEL-B0007H	TEL-B0057H	TEL-B2017H	TEL-B2067H	BK-T318
TEL-B28	TEL-B78	TEL-B0008H	TEL-B2019H			BK-T401
TEL-B29	TEL-B79	TEL-B0009H	TEL-B0059H	TEL-B2020H	TEL-B2070H	BK-T402
TEL-B30	TEL-B80	TEL-B0010H	TEL-B0060H	TEL-B2021H	TEL-B2071H	BK-T403
TEL-B31	TEL-B81	TEL-B0011H	TEL-B0061H	TEL-B2022H	TEL-B2072H	BK-T404
	TEL-B82	TEL-B0012H	TEL-B0062H	TEL-B2023H	TEL-B2073H	BK-T405
TEL-B33	TEL-B83	TEL-B0013H	TEL-B0063H	TEL-B2024H	TEL-B2074H	BK-T406
TEL-B34	TEL-B84	TEL-B0014H	TEL-B0064H	TEL-B2025H		
TEL-B35	TEL-B85	TEL-B0015H		TEL-B2026H		
TEL-B36	TEL-B86	TEL-B0016H	TEL-B0066H	TEL-B2027H	TEL-B2077H	BK-T411
TEL-B37	TEL-B87	TEL-B0017H	TEL-B0067H	TEL-B2028H	TEL-B2078H	BK-T407
TEL-B38	TEL-B88	TEL-B0018H	TEL-B0068H	TEL-B2029H		BK-T409
TEL-B39	TEL-B89	TEL-B0020H	TEL-B0070H			BK-T412
	TEL-B90	TEL-B0019H	TEL-B0069H	TEL-B2030H		

コードレス電話機用 充電電池適応表

充電式ニッケル水素電池

コードレス電話機



家庭用FAX



⚠️ 安全に関するご注意

⚠️ 警告 この表示を無視して誤った取り扱いをすると、人が死亡、または重傷を負う可能性が想定される内容を示しています。

- 本品の分解・改造は絶対にしないでください。液漏れ、発熱、破裂のおそれがあり、ケガをする危険があります。
- 濡れた手で電池、またはコネクタを触らないこと。
- 電池の被覆を剥がしたり傷つけないこと。
- 端子を針金などで接触させてショートさせないこと。
- 加熱したり、水に浸したり、火中に投げないこと。
- 幼児の手の届かない所に保管してください。
- 万一、電解液が皮膚や衣服に付いた場合は、直ちに水で洗い流してください。また、目に入ったときはきれいな水で洗った後、医師の診断を受けてください。

⚠️ 注意 この表示を無視して誤った取り扱いをすると、人が傷害を負う可能性が想定される内容、および物的損傷の発生が想定される内容を示しています。

- この電池パックはコードレス電話・FAX専用です。
- 適応機種以外には使用しないでください。
- リード線を切断、または引っ張らないこと。
- 落下させるなどの強い衝撃を与えないこと。
- セットするときにコードを挟まないように注意してください。
- 充電は所定の電話機にセットして行ってください。
- お使いいただく前に電話機・FAXの取扱説明書の電池に関する内容をよく読んでください。

◎OHM 株式会社 オーム電機
〒342-8502 埼玉県吉川市旭3-8
<http://www.ohm-electric.co.jp>

製品に関するお問い合わせは お客様相談室へ
●通話料無料 ●携帯・IP・公衆電話からは
0120-963-006 048-992-2735
電話受付 平日 9:00~17:00
※土曜・日曜・祝日及び年末年始は除きます

この適応表に記載の内容は 2019年7月現在のものです。

商品改良のため、仕様及び外観は予告なく変更される場合があります。

かんたん便利なWEB検索!

QRコードから簡単に
互換充電電池 適合検索画面へ
アクセスできます!

▼QRコードを読み取ってください!



<http://www.ohm-electric.co.jp/telbattery/>

■選べる2タイプ! 充電済だから買ってすぐ使える! ※1

※1 購入時の状態により充電が必要な場合があります。使用できない場合、ご使用になる機器の取扱説明書をよくお読みのうえ、満充電してください。

繰り返し充電に強い!

長持ち性能 ※2
繰り返し充電に強く、長持ちです。
※2 従来比 / JIS規格の試験方法に基づいた電池寿命の目安です。

自然放電制御
ご購入後すぐに使え、充電しておけば1年後でも使用が可能です。

長持ちタイプ

高容量! 通話時間UP

通話時間アップ ※3
従来品の 800mAh / 700mAh クラスの充電電池に比べ、1200mAh / 800mAh に容量がアップされています。
※3 ・当社前モデル比
・TEL-B 90 は純正電池と同じ 500mA となります
長期間使用しなかった場合、必ず所定の電話機にセットし、初期充電(10時間以上)してからご使用ください。

高容量タイプ

■安全装置内蔵

過電流を防止する安全装置が組み込まれています。

■環境対応 Ni-MH (ニッケル水素充電電池)

有害物質のカドミウムを含んでいません。また、ニッケルなどの希少物質を資源としてリサイクルできる、地球環境にやさしい充電電池です。



リサイクルのご協力をお願いします

交換した電池は捨てないで、コネクタにテープなどを貼り付けて絶縁してから充電式電池リサイクル協力店へお渡しください。

使用方法	使用温度範囲
ご使用前にコードレス電話機・FAXの取扱説明書をよくお読みください。 1. コネクタを正しい向きにしっかりと差し込んでください。 2. 電池フタを戻すときにコードを挟まないようにご注意ください。	機器使用: 0℃ ~ 45℃ 充電: 10℃ ~ 35℃ 保存: -20℃ ~ 35℃

充電電池の取り替え目安

充電電池には寿命があります。次の様な症状が出たらお早めに新しい充電電池とお取り替えください。

✔ いっぱい充電してもすぐに充電切れになる



✔ 子機を取り上げると警告音が鳴る

子機の仕様によっては鳴らないこともあります。



互換充電電池の探し方

A・B・Cの3通りの探し方があります。お選びになった電池パックは、ご使用済みの電池パックと形状が同じであることをご確認ください。

A 電話機・増設子機・FAX・複合機の『本体型番』から探す ⇒ 5~21ページ

電話機・増設子機・FAX・複合機の『本体型番』から探す

本体型番	メーカー	本体型番	メーカー	本体型番	メーカー
CJ-63Y	TEL-825	CJ-KE8	TEL-825	CJ-N853W	TEL-833
CJ-64Y	TEL-825	CJ-KE8B	TEL-825	CJ-N833W	TEL-833
CJ-65Y	TEL-825	CJ-KG1	TEL-825	CJ-NB77CL	TEL-833
CJ-66Y	TEL-825	CJ-KM3-H	TEL-825	CJ-NB773W	TEL-833
CJ-67Y	TEL-825	CJ-KM8-H	TEL-825	CJ-NB773W	TEL-825
CJ-630WY	TEL-825	CJ-KM30	TEL-825	CJ-PS3	TEL-825
CJ-640TY	TEL-825	CJ-K51	TEL-825	CJ-PS3	TEL-825
CJ-640WY	TEL-825	CJ-K52	TEL-825	CJ-PW22	TEL-825
CJ-650WY	TEL-825	CJ-K53	TEL-825	CJ-PW33	TEL-825
CJ-670WY	TEL-825	CJ-K54	TEL-825	CJ-SS1CL	TEL-825
				CJ-T51	TEL-825

① お使いの電話機・増設子機・FAX・複合機の『メーカー』を探す
② お使いの電話機・増設子機・FAX・複合機の『本体型番』を探す ※アルファベット順に並んでいます
→ 適合する充電電池の型番です

本体型番適応表の色分けについて
電話機 増設子機 FAX 複合機

B メーカー『純正充電電池の型番/部品番号』で探す ⇒ 22ページ

メーカー『純正充電電池の型番/部品番号』で探す

電話機・FAX・メーカー	メーカー充電電池型番/部品番号	本体型番	電話機・FAX・メーカー	メーカー充電電池型番/部品番号	本体型番
A-002	TEL-829	TEL-879	NTL-14	TEL-824	TEL-874
M-003	TEL-833	TEL-883	NTL-200	TEL-836	TEL-886
M-224	TEL-890		CT-電池パック-033	TEL-825	TEL-875
N-141	TEL-825	TEL-875	CT-電池パック-062	TEL-829	TEL-879
N-153	TEL-871	TEL-871	CT-電池パック-064	TEL-871	TEL-871
LIBATHN0153AF2Z	TEL-871	TEL-871	CT-電池パック-074	TEL-825	TEL-875

① お使いの電話機・増設子機・FAX・複合機の『メーカー』を探す
② お使いのメーカー充電電池の『型番/部品番号』を探す
→ 適合する充電電池の型番です

C オーム電機のホームページから探す ⇒ <http://www.ohm-electric.co.jp/telbattery/>

QRコードから簡単アクセス



① お使いの電話機・増設子機・FAX・複合機の『充電電池型番』または『本体型番』を入力して検索する

例) お使いの純正充電電池の型番がシャープ『M-003』の場合

OHM旧型番、純正充電電池型番、電話機・FAX・複合機の型番を入力してください

【検索例】 JD-AT82 【入力例】 AT82

① M-003

検索 リセット

例) お使いの電話機の型番がシャープ『JD-AT81CL』の場合

OHM旧型番、純正充電電池型番、電話機・FAX・複合機の型番を入力してください

【検索例】 JD-AT82 【入力例】 AT82

① JD-AT81CL

検索 リセット

適合する充電電池が表示されます

適合充電電池商品

【適合充電電池】 長持ちタイプ
【品番】 05-0033 【型番】 TEL-B33
【定格電圧】 2.4V 【定格容量】 800mAh
【JANコード】 4971275500334

【適合充電電池】 高容量タイプ
【品番】 05-0083 【型番】 TEL-B83
【定格電圧】 2.4V 【定格容量】 800mAh
【JANコード】 4971275500839

TEL-B71
高容量タイプ



■定格電圧 3.6V
■定格容量
高容量タイプ：600mAh
■対応メーカー純正電池型番
パナソニック：P-AA23/1BA01
KX-AN34
KX-AN34H
NTT：CT-電池パック-064
シャープ：N-153
UBATN0153AFZZ

TEL-B22
長持ちタイプ



TEL-B72
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN37
NTT：CT-電池パック-078

TEL-B31
長持ちタイプ



TEL-B81
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN50
NTT：CT-電池パック-085

TEL-B82
高容量タイプ



■定格電圧 2.4V
■定格容量
高容量タイプ：850mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN52
NTT：CT-電池パック-096

TEL-B23
長持ちタイプ



TEL-B73
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
パイオニア：FEX1048・FEX1049
FEX1056・FEX1069
FEX1072・TF-BT07
日立：BP2R4V-600N
BP2R4V-600

TEL-B24
長持ちタイプ



TEL-B74
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
サンヨー：NTL-14

TEL-B33
長持ちタイプ



TEL-B83
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
シャープ：M-003
NTT：CT-電池パック-086
CT-電池パック-087
キヤノン：HBT500

TEL-B34
長持ちタイプ



TEL-B84
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パイオニア：TF-BT20・TF-BT22
ユニデン：BT-794・BT-862
NEC：SP-N2

TEL-B25
長持ちタイプ



TEL-B75
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
シャープ：UX-BTK1・N-141
パイオニア：FEX1065/1070/1073
TF-BT09
ブラザー：BCL-BT
NTT：CT-電池パック-074/080
東芝：純正電池の品番なし

TEL-B26
長持ちタイプ



TEL-B76
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
パナソニック：BTA005AE
BTA021AE
UG-4403
P-AA42/1BA01
NTT：CT-電池パック-033
日立：BP2R4V-700

TEL-B35
長持ちタイプ



TEL-B85
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
NEC：SP-D3
NTT：CT-電池パック-099

TEL-B36
長持ちタイプ



TEL-B86
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
サンヨー：NTL-200・TEL-BT200

TEL-B27
長持ちタイプ



TEL-B77
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：900mAh
高容量タイプ：1200mAh
■対応メーカー純正電池型番
NEC：SP-N1・NB-R24/M/S/SK
キヤノン：HBT100・HBT200
HBT300
ユニデン：UXB1・UXB2
ソニー：BP-T50

TEL-B28
長持ちタイプ



TEL-B78
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：HHR05TA3A12
BT76228A/B
UG-4405
HHR-TA3/1BA1
キヤノン：DBT100
NTT：CT-電池パック-077

TEL-B37
長持ちタイプ



TEL-B87
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN51
NTT：CT-電池パック-092

TEL-B38
長持ちタイプ



TEL-B88
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN55
NTT：CT-電池パック-108

TEL-B29
長持ちタイプ



TEL-B79
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
シャープ：A-002
NTT：CT-電池パック-062
CT-電池パック-098
CT-電池パック-107

TEL-B30
長持ちタイプ



TEL-B80
高容量タイプ



■定格電圧 3.6V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN39
パイオニア：TF-BT10
FEX1079・FEX1080
ブラザー：BCL-BT30
NTT：CT-電池パック-093

TEL-B39
長持ちタイプ



TEL-B89
高容量タイプ



■定格電圧 2.4V
■定格容量
長持ちタイプ：800mAh
高容量タイプ：800mAh
■対応メーカー純正電池型番
パナソニック：KX-FAN57

TEL-B90
500mAhタイプ



■定格電圧 2.4V
■定格容量：500mAh
■対応メーカー純正電池型番
シャープ：M-224

シャープ

本体型番	◎機能型番		本体型番	◎機能型番		本体型番	◎機能型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CJ-63Y	TEL-B25	TEL-B75	CJ-KE8	TEL-B25	TEL-B75	CJ-N853W	TEL-B33	TEL-B83
CJ-64Y	TEL-B25	TEL-B75	CJ-KE8B	TEL-B25	TEL-B75	CJ-N883W	TEL-B33	TEL-B83
CJ-65Y	TEL-B25	TEL-B75	CJ-KG1	TEL-B25	TEL-B75	CJ-NB77CL	TEL-B33	TEL-B83
CJ-66Y	TEL-B25	TEL-B75	CJ-KM3-H	TEL-B25	TEL-B75	CJ-NB773W	TEL-B33	TEL-B83
CJ-67Y	TEL-B25	TEL-B75	CJ-KM8-H	TEL-B25	TEL-B75	CJ-PS2	TEL-B25	TEL-B75
CJ-630WY	TEL-B25	TEL-B75	CJ-KM30	TEL-B25	TEL-B75	CJ-PS3	TEL-B25	TEL-B75
CJ-640TY	TEL-B25	TEL-B75	CJ-KS1	TEL-B25	TEL-B75	CJ-PS5	TEL-B25	TEL-B75
CJ-640WY	TEL-B25	TEL-B75	CJ-KS2	TEL-B25	TEL-B75	CJ-PW22	TEL-B25	TEL-B75
CJ-650WY	TEL-B25	TEL-B75	CJ-KS3	TEL-B25	TEL-B75	CJ-PW33	TEL-B25	TEL-B75
CJ-670WY	TEL-B25	TEL-B75	CJ-KS4	TEL-B25	TEL-B75	CJ-SS1CL	TEL-B25	TEL-B75
CJ-755	TEL-B25	TEL-B75	CJ-KS5	TEL-B25	TEL-B75	CJ-TS1	TEL-B25	TEL-B75
CJ-755W	TEL-B25	TEL-B75	CJ-KS7	TEL-B25	TEL-B75	CJ-V10CL	TEL-B33	TEL-B83
CJ-765	TEL-B33	TEL-B83	CJ-KS50	TEL-B33	TEL-B83	CJ-V31CL	TEL-B33	TEL-B83
CJ-765W	TEL-B33	TEL-B83	CJ-KS60	TEL-B33	TEL-B83	CJ-V61CL	TEL-B25	TEL-B75
CJ-775	TEL-B33	TEL-B83	CJ-KS80	TEL-B33	TEL-B83	CJ-V61KT	TEL-B25	TEL-B75
CJ-775W	TEL-B33	TEL-B83	CJ-KV70	TEL-B25	TEL-B75	CJ-V61KW	TEL-B25	TEL-B75
CJ-D3	TEL-B25	TEL-B75	CJ-KV71	TEL-B25	TEL-B75	CJ-V70CL	TEL-B25	TEL-B75
CJ-D100	TEL-B25	TEL-B75	CJ-KV75	TEL-B25	TEL-B75	CJ-V70CW	TEL-B25	TEL-B75
CJ-D170	TEL-B25	TEL-B75	CJ-KV80	TEL-B25	TEL-B75	CJ-V71CL	TEL-B25	TEL-B75
CJ-D300	TEL-B25	TEL-B75	CJ-KV90	TEL-B25	TEL-B75	CJ-V71CW	TEL-B25	TEL-B75
CJ-DW17	TEL-B25	TEL-B75	CJ-L1	TEL-B25	TEL-B75	CJ-V73CL	TEL-B25	TEL-B75
CJ-E7	TEL-B25	TEL-B75	CJ-L6	TEL-B25	TEL-B75	CJ-V73CW	TEL-B25	TEL-B75
CJ-E8	TEL-B25	TEL-B75	CJ-L7	TEL-B25	TEL-B75	CJ-V74CL	TEL-B25	TEL-B75
CJ-E10	TEL-B25	TEL-B75	CJ-L67	TEL-B25	TEL-B75	CJ-V75CL	TEL-B25	TEL-B75
CJ-E78	TEL-B25	TEL-B75	CJ-L100	TEL-B25	TEL-B75	CJ-V75CW	TEL-B25	TEL-B75
CJ-E700	TEL-B25	TEL-B75	CJ-L300EX	TEL-B25	TEL-B75	CJ-V77CL	TEL-B25	TEL-B75
CJ-EW11	TEL-B25	TEL-B75	CJ-L600	TEL-B25	TEL-B75	CJ-V77KT	TEL-B25	TEL-B75
CJ-G1	TEL-B25	TEL-B75	CJ-LT111	TEL-B25	TEL-B75	CJ-V77KW	TEL-B25	TEL-B75
CJ-G2	TEL-B25	TEL-B75	CJ-LW11	TEL-B25	TEL-B75	CJ-V80CL	TEL-B25	TEL-B75
CJ-G6	TEL-B25	TEL-B75	CJ-LW66	TEL-B25	TEL-B75	CJ-V80CW	TEL-B25	TEL-B75
CJ-G8	TEL-B25	TEL-B75	CJ-LW77	TEL-B25	TEL-B75	CJ-V81CL	TEL-B25	TEL-B75
CJ-G600	TEL-B25	TEL-B75	CJ-LW670	TEL-B25	TEL-B75	CJ-V81CW	TEL-B25	TEL-B75
CJ-GW11	TEL-B25	TEL-B75	CJ-M3	TEL-B25	TEL-B75	CJ-V83CL	TEL-B25	TEL-B75
CJ-GW66	TEL-B25	TEL-B75	CJ-M3SX	TEL-B25	TEL-B75	CJ-V83CL-X	TEL-B25	TEL-B75
CJ-H1	TEL-B25	TEL-B75	CJ-M8	TEL-B25	TEL-B75	CJ-V83KW	TEL-B25	TEL-B75
CJ-H6	TEL-B25	TEL-B75	CJ-M30SL	TEL-B25	TEL-B75	CJ-V90CL	TEL-B25	TEL-B75
CJ-H7	TEL-B25	TEL-B75	CJ-M30SW	TEL-B25	TEL-B75	CJ-V90CW	TEL-B25	TEL-B75
CJ-H100	TEL-B25	TEL-B75	CJ-M101	TEL-B25	TEL-B75	CJ-V91CL	TEL-B25	TEL-B75
CJ-H600	TEL-B25	TEL-B75	CJ-MW8	TEL-B25	TEL-B75	CJ-V91KW	TEL-B25	TEL-B75
CJ-H700	TEL-B25	TEL-B75	CJ-MW33	TEL-B25	TEL-B75	CJ-V313W	TEL-B33	TEL-B83
CJ-HW11	TEL-B25	TEL-B75	CJ-MW102	TEL-B25	TEL-B75	CJ-V743W	TEL-B25	TEL-B75
CJ-HW77	TEL-B25	TEL-B75	CJ-N75CL	TEL-B25	TEL-B75	CJ-VP3CL	TEL-B25	TEL-B75
CJ-J1	TEL-B25	TEL-B75	CJ-N75CW	TEL-B25	TEL-B75	CJ-VP7CL	TEL-B25	TEL-B75
CJ-J2	TEL-B25	TEL-B75	CJ-N76CL	TEL-B33	TEL-B83	CJ-VP8CL	TEL-B25	TEL-B75
CJ-J100	TEL-B25	TEL-B75	CJ-N77CL	TEL-B33	TEL-B83	CJ-W10	TEL-B25	TEL-B75
CJ-JW11	TEL-B25	TEL-B75	CJ-N85CL	TEL-B33	TEL-B83	CJ-W11	TEL-B25	TEL-B75
CJ-JW22	TEL-B25	TEL-B75	CJ-N88CL	TEL-B33	TEL-B83	CJ-W100CL	TEL-B25	TEL-B75
CJ-KE7	TEL-B25	TEL-B75	CJ-N763W	TEL-B33	TEL-B83	CJ-X51	TEL-B25	TEL-B75
CJ-KE7B	TEL-B25	TEL-B75	CJ-N773W	TEL-B33	TEL-B83	CJ-X51W	TEL-B25	TEL-B75

シャープ

本体型番	◎機能型番		本体型番	◎機能型番		本体型番	◎機能型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CJ-X55CL	TEL-B25	TEL-B75	JD-G56CW	TEL-B33	TEL-B83	JD-V37CL	TEL-B33	TEL-B83
CJ-X55CW	TEL-B25	TEL-B75	JD-G60CL	TEL-B33	TEL-B83	JD-V37CW	TEL-B33	TEL-B83
CJ-X72	TEL-B25	TEL-B75	JD-G60CW	TEL-B33	TEL-B83	JD-VF1CL	TEL-B33	TEL-B83
CJ-X72W	TEL-B25	TEL-B75	JD-GE55CL	TEL-B33	TEL-B83	UX-17CL	TEL-B25	TEL-B75
CJ-X505	TEL-B25	TEL-B75	JD-GE55CW	TEL-B33	TEL-B83	UX-18CL	TEL-B25	TEL-B75
CJ-X707	TEL-B25	TEL-B75	JD-GE56CL	TEL-B33	TEL-B83	UX-18CW	TEL-B25	TEL-B75
CJ-X717	TEL-B25	TEL-B75	JD-GE56CW	TEL-B33	TEL-B83	UX-81E9CL	TEL-B33	TEL-B83
CJ-XW55	TEL-B25	TEL-B75	JD-K4C1		TEL-B90	UX-81E9CW	TEL-B33	TEL-B83
JD-3C1CL/CW		TEL-B90	JD-K4C2		TEL-B90	UX-150CL	TEL-B25	TEL-B75
JD-4C1CL/CW		TEL-B90	JD-KS11	TEL-B29	TEL-B79	UX-150CW	TEL-B25	TEL-B75
JD-4C2CL/CW		TEL-B90	JD-KS15	TEL-B29	TEL-B79	UX-155CL	TEL-B25	TEL-B75
JD-7C1CL	TEL-B29	TEL-B79	JD-KS17	TEL-B29	TEL-B79	UX-155CW	TEL-B25	TEL-B75
JD-7C1CW	TEL-B29	TEL-B79	JD-KS18	TEL-B29	TEL-B79	UX-159CL	TEL-B25	TEL-B75
JD-7C2CL	TEL-B33	TEL-B83	JD-KS21	TEL-B29	TEL-B79	UX-159CW	TEL-B25	TEL-B75
JD-7C2CW	TEL-B33	TEL-B83	JD-KS25	TEL-B29	TEL-B79	UX-310CL	TEL-B33	TEL-B83
JD-310CL	TEL-B29	TEL-B79	JD-KS28	TEL-B29	TEL-B79	UX-310CW	TEL-B33	TEL-B83
JD-310CW	TEL-B29	TEL-B79	JD-KS50-B	TEL-B33	TEL-B83	UX-320CL	TEL-B33	TEL-B83
JD-320CL	TEL-B29	TEL-B79	JD-KS100	TEL-B33	TEL-B83	UX-320CW	TEL-B33	TEL-B83
JD-320CW	TEL-B29	TEL-B79	JD-KS110	TEL-B33	TEL-B83	UX-350CL	TEL-B25	TEL-B75
JD-700CL	TEL-B29	TEL-B79	JD-KS120	TEL-B33	TEL-B83	UX-350CW	TEL-B25	TEL-B75
JD-700CW	TEL-B29	TEL-B79	JD-KS200	TEL-B33	TEL-B83	UX-353CL	TEL-B25	TEL-B75
JD-710CL	TEL-B29	TEL-B79	JD-KS210	TEL-B33	TEL-B83	UX-453CL	TEL-B25	TEL-B75
JD-710CW	TEL-B29	TEL-B79	JD-KS700	TEL-B33	TEL-B83	UX-500CL	TEL-B25	TEL-B75
JD-AT80CL	TEL-B33	TEL-B83	JD-KT500	TEL-B33	TEL-B83	UX-501CL	TEL-B25	TEL-B75
JD-AT80CW	TEL-B33	TEL-B83	JD-KT510	TEL-B33	TEL-B83	UX-501CW	TEL-B25	TEL-B75
JD-AT81CL	TEL-B33	TEL-B83	JD-LD8	TEL-B29	TEL-B79	UX-509CL	TEL-B25	TEL-B75
JD-AT81CW	TEL-B33	TEL-B83	JD-LW88	TEL-B29	TEL-B79	UX-559CL	TEL-B25	TEL-B75
JD-AT82CE	TEL-B33	TEL-B83	JD-N51CL	TEL-B29	TEL-B79	UX-600CL	TEL-B33	TEL-B83
JD-AT82CL	TEL-B33	TEL-B83	JD-N51CW	TEL-B29	TEL-B79	UX-600CW	TEL-B33	TEL-B83
JD-AT82CW	TEL-B33	TEL-B83	JD-N52CL	TEL-B29	TEL-B79	UX-608CL	TEL-B25	TEL-B75
JD-AT85C	TEL-B33	TEL-B83	JD-N52CW	TEL-B29	TEL-B79	UX-610CL	TEL-B33	TEL-B83
JD-AT85CL	TEL-B33	TEL-B83	JD-S05CL/CW		TEL-B90	UX-610CW	TEL-B33	TEL-B83
JD-AT85CW	TEL-B33	TEL-B83	JD-S05FG		TEL-B90	UX-650CL	TEL-B33	TEL-B83
JD-BC1CL/CW		TEL-B90	JD-S06CL/CW		TEL-B90	UX-650CW	TEL-B33	TEL-B83
JD-E301CL	TEL-B29	TEL-B79	JD-S07CL	TEL-B33	TEL-B83	UX-810CL	TEL-B33	TEL-B83
JD-E310CW	TEL-B29	TEL-B79	JD-S07CW	TEL-B33	TEL-B83	UX-810CW	TEL-B33	TEL-B83
JD-E502CL	TEL-B29	TEL-B79	JD-S08CL	TEL-B33	TEL-B83	UX-850CL	TEL-B33	TEL-B83
JD-G30CL	TEL-B33	TEL-B83	JD-S08CW	TEL-B33	TEL-B83	UX-850CW	TEL-B33	TEL-B83
JD-G30CW	TEL-B33	TEL-B83	JD-S10CL	TEL-B29	TEL-B79	UX-900CL	TEL-B33	TEL-B83
JD-G31CL	TEL-B33	TEL-B83	JD-S10CW	TEL-B29	TEL-B79	UX-900CW	TEL-B33	TEL-B83
JD-G31CW	TEL-B33	TEL-B83	JD-SF1CL		TEL-B90	UX-AF90CL	TEL-B33	TEL-B83
JD-G32CL	TEL-B33	TEL-B83	JD-V32CL	TEL-B29	TEL-B79	UX-AF90CW	TEL-B33	TEL-B83
JD-G32CW	TEL-B33	TEL-B83	JD-V32CW	TEL-B29	TEL-B79	UX-AF91CL	TEL-B33	TEL-B83
JD-G40CL	TEL-B33	TEL-B83	JD-V33CL	TEL-B29	TEL-B79	UX-AF91CW	TEL-B33	TEL-B83
JD-G40CW	TEL-B33	TEL-B83	JD-V33CW	TEL-B29	TEL-B79	UX-C107CL	TEL-B29	TEL-B79
JD-G55C	TEL-B33	TEL-B83	JD-V35CL	TEL-B33	TEL-B83	UX-C204CL	TEL-B33	TEL-B83
JD-G55CL	TEL-B33	TEL-B83	JD-V35CW	TEL-B33	TEL-B83	UX-D16CL	TEL-B29	TEL-B79
JD-G55CW	TEL-B33	TEL-B83	JD-V36CL	TEL-B33	TEL-B83	UX-D16CW	TEL-B29	TEL-B79
JD-G56CL	TEL-B33	TEL-B83	JD-V36CW	TEL-B33	TEL-B83	UX-D17CL	TEL-B29	TEL-B79

シャープ

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
UX-D17CW	TEL-B29	TEL-B79	UX-E306CW	TEL-B29	TEL-B79	UX-MF10CW	TEL-B33	TEL-B83
UX-D18CL	TEL-B29	TEL-B79	UX-E407CL	TEL-B29	TEL-B79	UX-MF25CL	TEL-B29	TEL-B79
UX-D18CW	TEL-B29	TEL-B79	UX-E407CW	TEL-B29	TEL-B79	UX-MF25CW	TEL-B29	TEL-B79
UX-D19CL	TEL-B29	TEL-B79	UX-E570CL	TEL-B29	TEL-B79	UX-MF30CL	TEL-B33	TEL-B83
UX-D19CW	TEL-B29	TEL-B79	UX-E570CW	TEL-B29	TEL-B79	UX-MF30CW	TEL-B33	TEL-B83
UX-D20CL	TEL-B29	TEL-B79	UX-E680CL	TEL-B29	TEL-B79	UX-MF40CL	TEL-B33	TEL-B83
UX-D20CW	TEL-B29	TEL-B79	UX-E680CW	TEL-B29	TEL-B79	UX-MF40CW	TEL-B33	TEL-B83
UX-D26CL	TEL-B29	TEL-B79	UX-E790CL	TEL-B29	TEL-B79	UX-MF50CL	TEL-B29	TEL-B79
UX-D26CW	TEL-B29	TEL-B79	UX-E790CW	TEL-B29	TEL-B79	UX-MF50CW	TEL-B29	TEL-B79
UX-D27CL	TEL-B29	TEL-B79	UX-E801CL	TEL-B33	TEL-B83	UX-MF60CL	TEL-B29	TEL-B79
UX-D27CW	TEL-B29	TEL-B79	UX-E801CW	TEL-B33	TEL-B83	UX-MF60CW	TEL-B29	TEL-B79
UX-D28CL	TEL-B29	TEL-B79	UX-F1CL	TEL-B25	TEL-B75	UX-MF70CL	TEL-B29	TEL-B79
UX-D28CW	TEL-B29	TEL-B79	UX-F1CL2	TEL-B25	TEL-B75	UX-MF70CW	TEL-B29	TEL-B79
UX-D30CL	TEL-B29	TEL-B79	UX-F2CL	TEL-B25	TEL-B75	UX-MF80CL	TEL-B29	TEL-B79
UX-D30CW	TEL-B29	TEL-B79	UX-F2CW	TEL-B25	TEL-B75	UX-MF80CW	TEL-B29	TEL-B79
UX-D32CL	TEL-B29	TEL-B79	UX-F2MR	TEL-B25	TEL-B75	UX-N15CL	TEL-B25	TEL-B75
UX-D32CW	TEL-B29	TEL-B79	UX-F3CL	TEL-B25	TEL-B75	UX-N15CW	TEL-B25	TEL-B75
UX-D33CL	TEL-B29	TEL-B79	UX-F4CL	TEL-B25	TEL-B75	UX-N150CL	TEL-B25	TEL-B75
UX-D33CW	TEL-B29	TEL-B79	UX-F4KW	TEL-B25	TEL-B75	UX-N155CL	TEL-B25	TEL-B75
UX-D56CL	TEL-B29	TEL-B79	UX-F5CL	TEL-B25	TEL-B75	UX-N155CW	TEL-B25	TEL-B75
UX-D56CW	TEL-B29	TEL-B79	UX-F5KW	TEL-B25	TEL-B75	UX-N159CL	TEL-B25	TEL-B75
UX-D57CL	TEL-B29	TEL-B79	UX-F10CL	TEL-B25	TEL-B75	UX-N159CW	TEL-B25	TEL-B75
UX-D57CW	TEL-B29	TEL-B79	UX-F10CW	TEL-B25	TEL-B75	UX-ND21V	TEL-B25	TEL-B75
UX-D58CL	TEL-B29	TEL-B79	UX-F11CL	TEL-B25	TEL-B75	UX-T7CL	TEL-B25	TEL-B75
UX-D58CW	TEL-B29	TEL-B79	UX-F12CL	TEL-B25	TEL-B75	UX-T7CL2	TEL-B25	TEL-B75
UX-D63CL	TEL-B29	TEL-B79	UX-F12CW	TEL-B25	TEL-B75	UX-T8CL	TEL-B25	TEL-B75
UX-D63CW	TEL-B29	TEL-B79	UX-F14CL	TEL-B25	TEL-B75	UX-T10CL	TEL-B25	TEL-B75
UX-D70CL	TEL-B29	TEL-B79	UX-F14CW	TEL-B25	TEL-B75	UX-T15CL	TEL-B25	TEL-B75
UX-D70CW	TEL-B29	TEL-B79	UX-F15CL	TEL-B25	TEL-B75	UX-T15CW	TEL-B25	TEL-B75
UX-D71CL	TEL-B29	TEL-B79	UX-F15CW	TEL-B25	TEL-B75	UX-T25CL	TEL-B25	TEL-B75
UX-D71CW	TEL-B29	TEL-B79	UX-F20CL	TEL-B25	TEL-B75	UX-T28CL	TEL-B25	TEL-B75
UX-D72CL	TEL-B29	TEL-B79	UX-F24CL	TEL-B33	TEL-B83	UX-T35CL	TEL-B25	TEL-B75
UX-D72CW	TEL-B29	TEL-B79	UX-F24CW	TEL-B33	TEL-B83	UX-T35CW	TEL-B25	TEL-B75
UX-D82CL	TEL-B29	TEL-B79	UX-F25CL	TEL-B33	TEL-B83	UX-T45CL	TEL-B25	TEL-B75
UX-D82CW	TEL-B29	TEL-B79	UX-F25CW	TEL-B33	TEL-B83	UX-T45CW	TEL-B25	TEL-B75
UX-D83CL	TEL-B29	TEL-B79	UX-F34CL	TEL-B33	TEL-B83	UX-T48CL	TEL-B25	TEL-B75
UX-D83CW	TEL-B29	TEL-B79	UX-F34CW	TEL-B33	TEL-B83	UX-T50CL	TEL-B25	TEL-B75
UX-D90CL	TEL-B29	TEL-B79	UX-F41CL	TEL-B25	TEL-B75	UX-T55CL	TEL-B25	TEL-B75
UX-D90CW	TEL-B29	TEL-B79	UX-F41KW	TEL-B25	TEL-B75	UX-T65CL	TEL-B25	TEL-B75
UX-D100CL	TEL-B29	TEL-B79	UX-F50CL	TEL-B33	TEL-B83	UX-TJ2CL	TEL-B25	TEL-B75
UX-D100CW	TEL-B29	TEL-B79	UX-F50CW	TEL-B33	TEL-B83	UX-TR3CL	TEL-B25	TEL-B75
UX-D110CL		TEL-B71	UX-F104Y	TEL-B25	TEL-B75	UX-V501CL	TEL-B25	TEL-B75
UX-D110CW		TEL-B71	UX-F250CL	TEL-B25	TEL-B75	UX-V501CW	TEL-B25	TEL-B75
UX-DK17CL	TEL-B29	TEL-B79	UX-F250CW	TEL-B25	TEL-B75	UX-V502CL	TEL-B25	TEL-B75
UX-E1CL	TEL-B25	TEL-B75	UX-F702CL	TEL-B25	TEL-B75	UX-V502CW	TEL-B25	TEL-B75
UX-E3CL	TEL-B25	TEL-B75	UX-F702CW	TEL-B25	TEL-B75	UX-V503CL	TEL-B33	TEL-B83
UX-E205CL	TEL-B33	TEL-B83	UX-FJ5CL	TEL-B25	TEL-B75	UX-V503CW	TEL-B33	TEL-B83
UX-E205CW	TEL-B33	TEL-B83	UX-K110CL		TEL-B71	UX-W30CL	TEL-B25	TEL-B75
UX-E306CL	TEL-B29	TEL-B79	UX-MF10CL	TEL-B33	TEL-B83	UX-W30CW	TEL-B25	TEL-B75

シャープ

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
UX-W31CL	TEL-B25	TEL-B75	UX-W60CW	TEL-B25	TEL-B75	UX-X1CL	TEL-B25	TEL-B75
UX-W31CW	TEL-B25	TEL-B75	UX-W70CL	TEL-B25	TEL-B75	UX-X1CW	TEL-B25	TEL-B75
UX-W40CL	TEL-B25	TEL-B75	UX-W70KW	TEL-B25	TEL-B75	UX-X2CL	TEL-B25	TEL-B75
UX-W50CL	TEL-B25	TEL-B75	UX-W71KW	TEL-B25	TEL-B75	UX-X2CW	TEL-B25	TEL-B75
UX-W51CL	TEL-B25	TEL-B75	UX-W90CL	TEL-B25	TEL-B75	UX-Y301CW	TEL-B25	TEL-B75
UX-W51CW	TEL-B25	TEL-B75	UX-W2000	TEL-B25	TEL-B75	UX-Y302CL	TEL-B25	TEL-B75
UX-W55CL	TEL-B33	TEL-B83	UX-WB10CL	TEL-B25	TEL-B75	UX-Y302CW	TEL-B25	TEL-B75
UX-W55CW	TEL-B33	TEL-B83	UX-WB10CW	TEL-B25	TEL-B75	UX-Y303CL	TEL-B33	TEL-B83
UX-W60CL	TEL-B25	TEL-B75	UX-WX71CL	TEL-B25	TEL-B75	UX-Y303CW	TEL-B33	TEL-B83

ソニー

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
SNF-5CL	TEL-B27	TEL-B77	SPP-C300	TEL-B27	TEL-B77	SPP-HC333	TEL-B27	TEL-B77
SNF-5CLW	TEL-B27	TEL-B77	SPP-C300PG	TEL-B27	TEL-B77	SPP-HC555	TEL-B27	TEL-B77
SNF-HS5	TEL-B27	TEL-B77	SPP-C303	TEL-B27	TEL-B77	SPP-HC700	TEL-B27	TEL-B77
SNF-HS6	TEL-B27	TEL-B77	SPP-C333	TEL-B27	TEL-B77	SPP-HE777	TEL-B27	TEL-B77
SNF-V6CL	TEL-B27	TEL-B77	SPP-C333PG	TEL-B27	TEL-B77	SPP-HS5	TEL-B27	TEL-B77
SPP-A500	TEL-B27	TEL-B77	SPP-C350	TEL-B27	TEL-B77	SPP-HS7	TEL-B27	TEL-B77
SPP-A500PKG	TEL-B27	TEL-B77	SPP-C350PG	TEL-B27	TEL-B77	SPP-HS55	TEL-B27	TEL-B77
SPP-A600	TEL-B27	TEL-B77	SPP-C500	TEL-B27	TEL-B77	SPP-HS77	TEL-B27	TEL-B77
SPP-C5	TEL-B27	TEL-B77	SPP-C500PG	TEL-B27	TEL-B77	SPP-HS99	TEL-B27	TEL-B77
SPP-C5PKG	TEL-B27	TEL-B77	SPP-C550	TEL-B27	TEL-B77	SPP-HS500	TEL-B27	TEL-B77
SPP-C7	TEL-B27	TEL-B77	SPP-C550PG	TEL-B27	TEL-B77	SPP-HS600	TEL-B27	TEL-B77
SPP-C7PKG	TEL-B27	TEL-B77	SPP-C555	TEL-B27	TEL-B77	SPP-L50	TEL-B27	TEL-B77
SPP-C55	TEL-B27	TEL-B77	SPP-C555PG	TEL-B27	TEL-B77	SPP-T33	TEL-B27	TEL-B77
SPP-C55PKG	TEL-B27	TEL-B77	SPP-C700	TEL-B27	TEL-B77	SPP-T33PG	TEL-B27	TEL-B77
SPP-C66	TEL-B27	TEL-B77	SPP-C700PG	TEL-B27	TEL-B77	SPP-T55	TEL-B27	TEL-B77
SPP-C70	TEL-B27	TEL-B77	SPP-C750	TEL-B27	TEL-B77	SPP-T55PG	TEL-B27	TEL-B77
SPP-C77	TEL-B27	TEL-B77	SPP-E777	TEL-B27	TEL-B77	SPP-VC111	TEL-B27	TEL-B77
SPP-C77PKG	TEL-B27	TEL-B77	SPP-E777PG	TEL-B27	TEL-B77	SPP-VT11	TEL-B27	TEL-B77
SPP-C99	TEL-B27	TEL-B77	SPP-G600PG	TEL-B27	TEL-B77			
SPP-C99PKG	TEL-B27	TEL-B77	SPP-HC111	TEL-B27	TEL-B77			

日立

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
HCT-C250	TEL-B23	TEL-B73	HCT-R300	TEL-B23	TEL-B73	HF-CL60	TEL-B23	TEL-B73
HCT-C270	TEL-B23	TEL-B73	HCT-R330	TEL-B23	TEL-B73	HF-CL66	TEL-B23	TEL-B73
HCT-C310	TEL-B23	TEL-B73	HCT-R500	TEL-B23	TEL-B73	HF-P88	TEL-B23	TEL-B73
HCT-C550	TEL-B23	TEL-B73	HF-C60S	TEL-B23	TEL-B73	HF-P88S	TEL-B23	TEL-B73
HCT-C570	TEL-B23	TEL-B73	HF-C70	TEL-B23	TEL-B73	HF-P98	TEL-B23	TEL-B73
HCT-C610	TEL-B23	TEL-B73	HF-C77	TEL-B23	TEL-B73	HF-S30	TEL-B26	TEL-B76
HCT-F350	TEL-B23	TEL-B73	HF-CL50	TEL-B26	TEL-B76	HF-TA50	TEL-B26	TEL-B76

パナソニック

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
KX-AN181		TEL-B71	KX-FKN551	TEL-B31	TEL-B81	KX-PD604SL	TEL-B38	TEL-B88
KX-AN182		TEL-B71	KX-L5CL	TEL-B22	TEL-B72	KX-PD604SL 親機	TEL-B39	TEL-B89
KX-AN184		TEL-B71	KX-L5CW	TEL-B22	TEL-B72	KX-PD615DL	TEL-B39	TEL-B89
KX-FAN185		TEL-B71	KX-L6CL	TEL-B22	TEL-B72	KX-PD615DW	TEL-B39	TEL-B89
KX-FKD401	TEL-B38	TEL-B88	KX-L6CW	TEL-B22	TEL-B72	KX-PD701DL	TEL-B38	TEL-B88
KX-FKD403	TEL-B38	TEL-B88	KX-PD101DL	TEL-B39	TEL-B89	KX-PD701DW	TEL-B38	TEL-B88
KX-FKD404	TEL-B39	TEL-B89	KX-PD102D	TEL-B39	TEL-B89	KX-PD702DL	TEL-B38	TEL-B88
KX-FKD502	TEL-B38	TEL-B88	KX-PD102DL	TEL-B39	TEL-B89	KX-PD702DW	TEL-B38	TEL-B88
KX-FKD503	TEL-B38	TEL-B88	KX-PD205DL	TEL-B39	TEL-B89	KX-PD703UD	TEL-B38	TEL-B88
KX-FKD505	TEL-B39	TEL-B89	KX-PD205DW	TEL-B39	TEL-B89	KX-PD703UW	TEL-B38	TEL-B88
KX-FKD506	TEL-B39	TEL-B89	KX-PD215DL	TEL-B39	TEL-B89	KX-PD715DL	TEL-B39	TEL-B89
KX-FKD602	TEL-B38	TEL-B88	KX-PD215DW	TEL-B39	TEL-B89	KX-PD715DW	TEL-B39	TEL-B89
KX-FKD603	TEL-B38	TEL-B88	KX-PD301DL	TEL-B38	TEL-B88	KX-PD915DL	TEL-B39	TEL-B89
KX-FKN22	TEL-B22	TEL-B72	KX-PD301DW	TEL-B38	TEL-B88	KX-PW5CL		TEL-B71
KX-FKN22H	TEL-B22	TEL-B72	KX-PD303DL	TEL-B38	TEL-B88	KX-PW6CL		TEL-B71
KX-FKN22K	TEL-B22	TEL-B72	KX-PD303DW	TEL-B38	TEL-B88	KX-PW6CL2		TEL-B71
KX-FKN22N	TEL-B22	TEL-B72	KX-PD304DL	TEL-B39	TEL-B89	KX-PW6CLW		TEL-B71
KX-FKN36	TEL-B22	TEL-B72	KX-PD304DW	TEL-B39	TEL-B89	KX-PW10CL		TEL-B71
KX-FKN55	TEL-B22	TEL-B72	KX-PD305DL	TEL-B39	TEL-B89	KX-PW10CL2		TEL-B71
KX-FKN76	TEL-B22	TEL-B72	KX-PD305DW	TEL-B39	TEL-B89	KX-PW10CL2W		TEL-B71
KX-FKN90	TEL-B22	TEL-B72	KX-PD315DL	TEL-B39	TEL-B89	KX-PW10CLW		TEL-B71
KX-FKN96	TEL-B22	TEL-B72	KX-PD315DW	TEL-B39	TEL-B89	KX-PW12CL	TEL-B22	TEL-B72
KX-FKN100	TEL-B31	TEL-B81	KX-PD502DL	TEL-B38	TEL-B88	KX-PW12CLW	TEL-B22	TEL-B72
KX-FKN110	TEL-B22	TEL-B72	KX-PD502DW	TEL-B38	TEL-B88	KX-PW16CL	TEL-B22	TEL-B72
KX-FKN300	TEL-B22	TEL-B72	KX-PD502UD	TEL-B38	TEL-B88	KX-PW22CL	TEL-B22	TEL-B72
KX-FKN310	TEL-B22	TEL-B72	KX-PD503DL	TEL-B39	TEL-B89	KX-PW22CLH	TEL-B22	TEL-B72
KX-FKN320	TEL-B22	TEL-B72	KX-PD503DW	TEL-B39	TEL-B89	KX-PW22CLK	TEL-B22	TEL-B72
KX-FKN330	TEL-B22	TEL-B72	KX-PD503UD	TEL-B39	TEL-B89	KX-PW32CL	TEL-B22	TEL-B72
KX-FKN340	TEL-B22	TEL-B72	KX-PD503UD 親機	TEL-B38	TEL-B88	KX-PW36CL	TEL-B22	TEL-B72
KX-FKN501D	TEL-B30	TEL-B80	KX-PD503UW	TEL-B39	TEL-B89	KX-PW36CLW	TEL-B22	TEL-B72
KX-FKN510	TEL-B31	TEL-B81	KX-PD503UW 親機	TEL-B38	TEL-B88	KX-PW37CL	TEL-B22	TEL-B72
KX-FKN511	TEL-B31	TEL-B81	KX-PD505DL	TEL-B39	TEL-B89	KX-PW38CL	TEL-B22	TEL-B72
KX-FKN512	TEL-B31	TEL-B81	KX-PD505DW	TEL-B39	TEL-B89	KX-PW42CL	TEL-B22	TEL-B72
KX-FKN513		TEL-B82	KX-PD515DL	TEL-B39	TEL-B89	KX-PW47CL	TEL-B22	TEL-B72
KX-FKN514		TEL-B82	KX-PD515DW	TEL-B39	TEL-B89	KX-PW48CL	TEL-B22	TEL-B72
KX-FKN515	TEL-B37	TEL-B87	KX-PD551D	TEL-B38	TEL-B88	KX-PW52CLH	TEL-B22	TEL-B72
KX-FKN516	TEL-B37	TEL-B87	KX-PD551DL	TEL-B38	TEL-B88	KX-PW55CL	TEL-B22	TEL-B72
KX-FKN518	TEL-B37	TEL-B87	KX-PD552D	TEL-B39	TEL-B89	KX-PW57CL	TEL-B22	TEL-B72
KX-FKN520	TEL-B31	TEL-B81	KX-PD552DL	TEL-B39	TEL-B89	KX-PW76CL	TEL-B22	TEL-B72
KX-FKN521	TEL-B31	TEL-B81	KX-PD552DW	TEL-B39	TEL-B89	KX-PW88CL	TEL-B22	TEL-B72
KX-FKN522		TEL-B82	KX-PD600DL	TEL-B39	TEL-B89	KX-PW90CL	TEL-B22	TEL-B72
KX-FKN523		TEL-B82	KX-PD600DW	TEL-B39	TEL-B89	KX-PW92CW	TEL-B22	TEL-B72
KX-FKN524		TEL-B82	KX-PD601DL	TEL-B38	TEL-B88	KX-PW93CL	TEL-B22	TEL-B72
KX-FKN526	TEL-B37	TEL-B87	KX-PD601DW	TEL-B38	TEL-B88	KX-PW93CW	TEL-B22	TEL-B72
KX-FKN530	TEL-B31	TEL-B81	KX-PD603D	TEL-B38	TEL-B88	KX-PW95CL	TEL-B22	TEL-B72
KX-FKN530-W	TEL-B31	TEL-B81	KX-PD603DL	TEL-B38	TEL-B88	KX-PW95CW	TEL-B22	TEL-B72
KX-FKN531	TEL-B31	TEL-B81	KX-PD603DW	TEL-B38	TEL-B88	KX-PW96CL	TEL-B22	TEL-B72
KX-FKN531-W	TEL-B31	TEL-B81	KX-PD604DL	TEL-B39	TEL-B89	KX-PW100CL	TEL-B31	TEL-B81
KX-FKN550	TEL-B31	TEL-B81	KX-PD604DW	TEL-B39	TEL-B89	KX-PW101CL	TEL-B22	TEL-B72

パナソニック

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
KX-PW102CW	TEL-B22	TEL-B72	KX-PW821DW	TEL-B37	TEL-B87	VE-D66L	TEL-B26	TEL-B76
KX-PW110CL	TEL-B22	TEL-B72	KX-PZ200DL	TEL-B39	TEL-B89	VE-D67L	TEL-B26	TEL-B76
KX-PW201CL	TEL-B22	TEL-B72	KX-PZ200DW	TEL-B39	TEL-B89	VE-D67NW	TEL-B26	TEL-B76
KX-PW201CW	TEL-B22	TEL-B72	KX-PZ210DL	TEL-B39	TEL-B89	VE-D70J	TEL-B26	TEL-B76
KX-PW211DL	TEL-B37	TEL-B87	KX-PZ300DL	TEL-B39	TEL-B89	VE-D75J	TEL-B26	TEL-B76
KX-PW301DL	TEL-B30	TEL-B80	KX-PZ300DW	TEL-B39	TEL-B89	VE-D76J	TEL-B26	TEL-B76
KX-PW308DL	TEL-B37	TEL-B87	KX-PZ500DL	TEL-B39	TEL-B89	VE-D78J	TEL-B26	TEL-B76
KX-PW308DW	TEL-B37	TEL-B87	KX-PZ500DW	TEL-B39	TEL-B89	VE-D80J	TEL-B26	TEL-B76
KX-PW320DL	TEL-B37	TEL-B87	KX-PZ510DL	TEL-B39	TEL-B89	VE-D81J	TEL-B26	TEL-B76
KX-PW320DW	TEL-B37	TEL-B87	KX-PZ610DL	TEL-B39	TEL-B89	VE-D83L	TEL-B26	TEL-B76
KX-PW501DL	TEL-B31	TEL-B81	KX-PZ610DW	TEL-B39	TEL-B89	VE-D85L	TEL-B26	TEL-B76
KX-PW501DW	TEL-B31	TEL-B81	KX-PZ710DL	TEL-B39	TEL-B89	VE-D86L	TEL-B26	TEL-B76
KX-PW503DL	TEL-B31	TEL-B81	KX-PZ710DW	TEL-B39	TEL-B89	VE-D90L	TEL-B26	TEL-B76
KX-PW503DW	TEL-B31	TEL-B81	KX-PZ910DL	TEL-B39	TEL-B89	VE-D90NW	TEL-B26	TEL-B76
KX-PW503UD	TEL-B31	TEL-B81	UE-303030	TEL-B26	TEL-B76	VE-D91L	TEL-B26	TEL-B76
KX-PW505DL	TEL-B31	TEL-B81	UF-A1CL	TEL-B26	TEL-B76	VE-D91NW	TEL-B26	TEL-B76
KX-PW505DW	TEL-B31	TEL-B81	UF-A1WCL	TEL-B26	TEL-B76	VE-DW57L	TEL-B26	TEL-B76
KX-PW506DL		TEL-B82	UF-A2CL	TEL-B26	TEL-B76	VE-DW90L	TEL-B26	TEL-B76
KX-PW506DW		TEL-B82	UF-A2CL/W	TEL-B26	TEL-B76	VE-DW91L	TEL-B26	TEL-B76
KX-PW507DL	TEL-B37	TEL-B87	UF-A2DL/H	TEL-B26	TEL-B76	VE-DX2	TEL-B26	TEL-B76
KX-PW507DW	TEL-B37	TEL-B87	UF-A3CL	TEL-B26	TEL-B76	VE-E10DL	TEL-B39	TEL-B89
KX-PW508DL	TEL-B37	TEL-B87	UF-A3CLH	TEL-B26	TEL-B76	VE-E10DW	TEL-B39	TEL-B89
KX-PW508DW	TEL-B37	TEL-B87	UF-A5CL	TEL-B26	TEL-B76	VE-GD21DL	TEL-B38	TEL-B88
KX-PW513DL	TEL-B31	TEL-B81	UF-A6CL	TEL-B26	TEL-B76	VE-GD21DW	TEL-B38	TEL-B88
KX-PW513DW	TEL-B31	TEL-B81	UF-A7WCL	TEL-B26	TEL-B76	VE-GD23DL	TEL-B38	TEL-B88
KX-PW520DL	TEL-B37	TEL-B87	UF-A8SCL	TEL-B26	TEL-B76	VE-GD23DW	TEL-B38	TEL-B88
KX-PW520DW	TEL-B37	TEL-B87	UF-A8WCL	TEL-B26	TEL-B76	VE-GD24DL	TEL-B39	TEL-B89
KX-PW521XL	TEL-B37	TEL-B87	UF-L1WCL	TEL-B28	TEL-B78	VE-GD24DW	TEL-B39	TEL-B89
KX-PW521XW	TEL-B37	TEL-B87	UF-L2CL	TEL-B28	TEL-B78	VE-GD25DL	TEL-B39	TEL-B89
KX-PW601DL	TEL-B31	TEL-B81	UF-L3CL	TEL-B28	TEL-B78	VE-GD25DW	TEL-B39	TEL-B89
KX-PW601DW	TEL-B31	TEL-B81	UF-L3WCL	TEL-B28	TEL-B78	VE-GD31DL	TEL-B38	TEL-B88
KX-PW603DB	TEL-B31	TEL-B81	UF-NA100	TEL-B26	TEL-B76	VE-GD31DW	TEL-B38	TEL-B88
KX-PW603DL	TEL-B31	TEL-B81	UF-NA150	TEL-B26	TEL-B76	VE-GD32DL	TEL-B39	TEL-B89
KX-PW603DW	TEL-B31	TEL-B81	UF-NA200	TEL-B26	TEL-B76	VE-GD32DW	TEL-B39	TEL-B89
KX-PW603UD	TEL-B31	TEL-B81	UF-NA200H	TEL-B26	TEL-B76	VE-GD35DL	TEL-B39	TEL-B89
KX-PW605DL	TEL-B31	TEL-B81	UF-NA200/W	TEL-B26	TEL-B76	VE-GD35DW	TEL-B39	TEL-B89
KX-PW605DW	TEL-B31	TEL-B81	UF-NA500	TEL-B26	TEL-B76	VE-GD51D	TEL-B38	TEL-B88
KX-PW606DL		TEL-B82	UF-NA550	TEL-B28	TEL-B78	VE-GD51DL	TEL-B38	TEL-B88
KX-PW606DW		TEL-B82	UF-NA600	TEL-B28	TEL-B78	VE-GD51DW	TEL-B38	TEL-B88
KX-PW607DL	TEL-B37	TEL-B87	UF-P2CL	TEL-B26	TEL-B76	VE-GD53D	TEL-B38	TEL-B88
KX-PW607DW	TEL-B37	TEL-B87	UF-P3CL	TEL-B26	TEL-B76	VE-GD53DL	TEL-B38	TEL-B88
KX-PW608DL	TEL-B37	TEL-B87	VE-CS210A	TEL-B22	TEL-B72	VE-GD53DW	TEL-B38	TEL-B88
KX-PW608DW	TEL-B37	TEL-B87	VE-CV02L	TEL-B22	TEL-B72	VE-GD55DL	TEL-B39	TEL-B89
KX-PW616DL		TEL-B82	VE-CV03	TEL-B22	TEL-B72	VE-GD55DW	TEL-B39	TEL-B89
KX-PW621DL	TEL-B37	TEL-B87	VE-CVW02L	TEL-B22	TEL-B72	VE-GD60DL	TEL-B39	TEL-B89
KX-PW621DW	TEL-B37	TEL-B87	VE-CVW03	TEL-B22	TEL-B72	VE-GD60DW	TEL-B39	TEL-B89
KX-PW820DL	TEL-B37	TEL-B87	VE-D57L	TEL-B26	TEL-B76	VE-GD71DL	TEL-B38	TEL-B88
KX-PW820DW	TEL-B37	TEL-B87	VE-D60J	TEL-B26	TEL-B76	VE-GD71DW	TEL-B38	TEL-B88
KX-PW821DL	TEL-B37	TEL-B87	VE-D63L	TEL-B26	TEL-B76	VE-GD72D	TEL-B39	TEL-B89

パナソニック

本体型番	◎機能型番		本体型番	◎機能型番		本体型番	◎機能型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
VE-GD72DL	TEL-B39	TEL-B89	VE-GP53DL	TEL-B37	TEL-B87	VE-PV55JK	TEL-B28	TEL-B78
VE-GD72DW	TEL-B39	TEL-B89	VE-GP53DW	TEL-B37	TEL-B87	VE-PV77L	TEL-B28	TEL-B78
VE-GDF61D	TEL-B39	TEL-B89	VE-GP54DL	TEL-B37	TEL-B87	VE-PVW01L	TEL-B28	TEL-B78
VE-GDF61DL	TEL-B39	TEL-B89	VE-GP54DW	TEL-B37	TEL-B87	VE-PVW3J	TEL-B28	TEL-B78
VE-GDS01DL	TEL-B38	TEL-B88	VE-GP55DL	TEL-B37	TEL-B87	VE-PVW5J	TEL-B28	TEL-B78
VE-GDS02DL	TEL-B39	TEL-B89	VE-GP55DW	TEL-B37	TEL-B87	VE-PVW33J	TEL-B28	TEL-B78
VE-GDW03DL	TEL-B39	TEL-B89	VE-GP62DL	TEL-B37	TEL-B87	VE-PVW33N	TEL-B28	TEL-B78
VE-GDW54D	TEL-B39	TEL-B89	VE-GP62DW	TEL-B37	TEL-B87	VE-PVW33T	TEL-B28	TEL-B78
VE-GDW54DL	TEL-B39	TEL-B89	VE-GZ20DL	TEL-B39	TEL-B89	VE-PVW55J	TEL-B28	TEL-B78
VE-GDW54DW	TEL-B39	TEL-B89	VE-GZ20DW	TEL-B39	TEL-B89	VE-PVW77L	TEL-B28	TEL-B78
VE-GE10DL	TEL-B39	TEL-B89	VE-GZ30DL	TEL-B39	TEL-B89	VE-R10J	TEL-B26	TEL-B76
VE-GE10DW	TEL-B39	TEL-B89	VE-GZ30DW	TEL-B39	TEL-B89	VE-R11J	TEL-B26	TEL-B76
VE-GP01DL	TEL-B31	TEL-B81	VE-GZ50DL	TEL-B39	TEL-B89	VE-SV01CL	TEL-B22	TEL-B72
VE-GP01DW	TEL-B31	TEL-B81	VE-GZ50DW	TEL-B39	TEL-B89	VE-SV02DL		TEL-B82
VE-GP02DL	TEL-B31	TEL-B81	VE-GZ61DL	TEL-B39	TEL-B89	VE-SV02DW		TEL-B82
VE-GP02DW	TEL-B31	TEL-B81	VE-GZ61DW	TEL-B39	TEL-B89	VE-SV03DL		TEL-B82
VE-GP03DL	TEL-B31	TEL-B81	VE-GZ71DL	TEL-B39	TEL-B89	VE-SV03DW		TEL-B82
VE-GP03DW	TEL-B31	TEL-B81	VE-GZ71DW	TEL-B39	TEL-B89	VE-SV06DL		TEL-B82
VE-GP03UD	TEL-B31	TEL-B81	VE-J06	TEL-B26	TEL-B76	VE-SV06DW		TEL-B82
VE-GP05DB	TEL-B31	TEL-B81	VE-J07	TEL-B26	TEL-B76	VE-SV07DL		TEL-B82
VE-GP05DL	TEL-B31	TEL-B81	VE-J08	TEL-B26	TEL-B76	VE-W50	TEL-B26	TEL-B76
VE-GP05DW	TEL-B31	TEL-B81	VE-J601	TEL-B26	TEL-B76	VE-W65J	TEL-B26	TEL-B76
VE-GP10DL		TEL-B82	VE-J651	TEL-B26	TEL-B76	VL-W600	TEL-B37	TEL-B87
VE-GP10DW		TEL-B82	VE-J801	TEL-B26	TEL-B76	VL-W601	TEL-B37	TEL-B87
VE-GP20DL		TEL-B82	VE-J811	TEL-B26	TEL-B76	VL-W602	TEL-B37	TEL-B87
VE-GP20DW		TEL-B82	VE-L10	TEL-B26	TEL-B76	VL-W603	TEL-B37	TEL-B87
VE-GP22DL		TEL-B82	VE-L11	TEL-B26	TEL-B76	VL-W605	TEL-B37	TEL-B87
VE-GP22DW		TEL-B82	VE-L11NW	TEL-B26	TEL-B76	VL-W606	TEL-B37	TEL-B87
VE-GP24DL	TEL-B37	TEL-B87	VE-L20	TEL-B26	TEL-B76	VL-W607	TEL-B37	TEL-B87
VE-GP24DW	TEL-B37	TEL-B87	VE-L21	TEL-B26	TEL-B76	VL-W610	TEL-B37	TEL-B87
VE-GP24TA	TEL-B37	TEL-B87	VE-L21NW	TEL-B26	TEL-B76	VL-WD608	TEL-B38	TEL-B88
VE-GP30DL		TEL-B82	VE-PS103N	TEL-B28	TEL-B78	VL-WD612	TEL-B38	TEL-B88
VE-GP30DW		TEL-B82	VE-PS104N	TEL-B28	TEL-B78	VL-WD614	TEL-B39	TEL-B89
VE-GP31DL		TEL-B82	VE-PS105N	TEL-B28	TEL-B78			
VE-GP31DW		TEL-B82	VE-PS106N	TEL-B28	TEL-B78			
VE-GP32DL	TEL-B37	TEL-B87	VE-PS107N	TEL-B28	TEL-B78			
VE-GP32DW	TEL-B37	TEL-B87	VE-PS108N	TEL-B28	TEL-B78			
VE-GP33DL	TEL-B37	TEL-B87	VE-PS109N	TEL-B28	TEL-B78			
VE-GP33DW	TEL-B37	TEL-B87	VE-PS110N	TEL-B28	TEL-B78			
VE-GP34DL	TEL-B37	TEL-B87	VE-PV01L	TEL-B28	TEL-B78			
VE-GP34DW	TEL-B37	TEL-B87	VE-PV1	TEL-B28	TEL-B78			
VE-GP35DL	TEL-B37	TEL-B87	VE-PV3J	TEL-B28	TEL-B78			
VE-GP35DW	TEL-B37	TEL-B87	VE-PV3T	TEL-B28	TEL-B78			
VE-GP50DL	TEL-B31	TEL-B81	VE-PV5J	TEL-B28	TEL-B78			
VE-GP50DW	TEL-B31	TEL-B81	VE-PV11L	TEL-B28	TEL-B78			
VE-GP51DL		TEL-B82	VE-PV33J	TEL-B28	TEL-B78			
VE-GP51DW		TEL-B82	VE-PV33N	TEL-B28	TEL-B78			
VE-GP52DL	TEL-B37	TEL-B87	VE-PV33T	TEL-B28	TEL-B78			
VE-GP52DW	TEL-B37	TEL-B87	VE-PV55J	TEL-B28	TEL-B78			

パイオニア

本体型番	◎機能型番		本体型番	◎機能型番		本体型番	◎機能型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
TF-AD1500	TEL-B30	TEL-B80	TF-DK120	TEL-B30	TEL-B80	TF-EVH33	TEL-B23	TEL-B73
TF-AD1530	TEL-B30	TEL-B80	TF-DK125	TEL-B30	TEL-B80	TF-EVH34	TEL-B23	TEL-B73
TF-AD1540	TEL-B30	TEL-B80	TF-DK130	TEL-B30	TEL-B80	TF-EVH113	TEL-B25	TEL-B75
TF-AD1600	TEL-B30	TEL-B80	TF-DK150	TEL-B30	TEL-B80	TF-EVH114	TEL-B25	TEL-B75
TF-AD1630	TEL-B30	TEL-B80	TF-DK155	TEL-B30	TEL-B80	TF-EVH123	TEL-B25	TEL-B75
TF-AD1640	TEL-B30	TEL-B80	TF-DK160	TEL-B30	TEL-B80	TF-EVH124	TEL-B25	TEL-B75
TF-AD5200	TEL-B30	TEL-B80	TF-DK170	TEL-B30	TEL-B80	TF-EVH133	TEL-B25	TEL-B75
TF-AD5205	TEL-B30	TEL-B80	TF-DK200	TEL-B30	TEL-B80	TF-EVH134	TEL-B25	TEL-B75
TF-AD5230	TEL-B30	TEL-B80	TF-DK200KT	TEL-B30	TEL-B80	TF-EVH303	TEL-B25	TEL-B75
TF-AD5235	TEL-B30	TEL-B80	TF-DK220	TEL-B30	TEL-B80	TF-EVH304	TEL-B25	TEL-B75
TF-AD5240	TEL-B30	TEL-B80	TF-DK300	TEL-B30	TEL-B80	TF-FA10S	TEL-B34	TEL-B84
TF-BS1	TEL-B23	TEL-B73	TF-DK500	TEL-B30	TEL-B80	TF-FA70S	TEL-B34	TEL-B84
TF-CV12	TEL-B23	TEL-B73	TF-DK520	TEL-B30	TEL-B80	TF-FA70T	TEL-B34	TEL-B84
TF-CV13	TEL-B23	TEL-B73	TF-DK555	TEL-B30	TEL-B80	TF-FA70W	TEL-B34	TEL-B84
TF-CV32	TEL-B23	TEL-B73	TF-DK720	TEL-B30	TEL-B80	TF-FA75S	TEL-B34	TEL-B84
TF-CV72	TEL-B23	TEL-B73	TF-DK820	TEL-B30	TEL-B80	TF-FA75W	TEL-B34	TEL-B84
TF-CV310	TEL-B25	TEL-B75	TF-E553D	TEL-B30	TEL-B80	TF-FD15S	TEL-B34	TEL-B84
TF-CV320	TEL-B25	TEL-B75	TF-E554D	TEL-B30	TEL-B80	TF-FD30S	TEL-B34	TEL-B84
TF-CVH33	TEL-B23	TEL-B73	TF-EK10	TEL-B34	TEL-B84	TF-FD31S	TEL-B34	TEL-B84
TF-CVH34	TEL-B23	TEL-B73	TF-EK30	TEL-B34	TEL-B84	TF-FD31T	TEL-B34	TEL-B84
TF-CVH73	TEL-B23	TEL-B73	TF-EK31	TEL-B34	TEL-B84	TF-FD31W	TEL-B34	TEL-B84
TF-CVH74	TEL-B23	TEL-B73	TF-EK32	TEL-B34	TEL-B84	TF-FD35S	TEL-B34	TEL-B84
TF-CVH313	TEL-B25	TEL-B75	TF-EK33	TEL-B34	TEL-B84	TF-FD35T	TEL-B34	TEL-B84
TF-CVH314	TEL-B25	TEL-B75	TF-EK34	TEL-B34	TEL-B84	TF-FD35W	TEL-B34	TEL-B84
TF-CVH323	TEL-B25	TEL-B75	TF-EK35	TEL-B34	TEL-B84	TF-FD1200	TEL-B30	TEL-B80
TF-CVH324	TEL-B25	TEL-B75	TF-EK36	TEL-B34	TEL-B84	TF-FD1220	TEL-B30	TEL-B80
TF-DH1	TEL-B23	TEL-B73	TF-EK37	TEL-B34	TEL-B84	TF-FD1230	TEL-B30	TEL-B80
TF-DH2	TEL-B23	TEL-B73	TF-EK70	TEL-B34	TEL-B84	TF-FD1500	TEL-B30	TEL-B80
TF-DH3	TEL-B23	TEL-B73	TF-EK71	TEL-B34	TEL-B84	TF-FD1520	TEL-B30	TEL-B80
TF-DH5	TEL-B23	TEL-B73	TF-EK72	TEL-B34	TEL-B84	TF-FD1530	TEL-B30	TEL-B80
TF-DH7	TEL-B23	TEL-B73	TF-EK73	TEL-B34	TEL-B84	TF-FE30S	TEL-B34	TEL-B84
TF-DH8	TEL-B23	TEL-B73	TF-EK75S	TEL-B34	TEL-B84	TF-FE30T	TEL-B34	TEL-B84
TF-DH33	TEL-B23	TEL-B73	TF-EV12	TEL-B23	TEL-B73	TF-FE30W	TEL-B34	TEL-B84
TF-DH55	TEL-B23	TEL-B73	TF-EV13	TEL-B23	TEL-B73	TF-FK9	TEL-B23	TEL-B73
TF-DH72	TEL-B23	TEL-B73	TF-EV14	TEL-B23	TEL-B73	TF-FK10	TEL-B23	TEL-B73
TF-DHS1	TEL-B23	TEL-B73	TF-EV20	TEL-B23	TEL-B73	TF-FK11	TEL-B23	TEL-B73
TF-DHS2	TEL-B23	TEL-B73	TF-EV32	TEL-B23	TEL-B73	TF-FK21	TEL-B23	TEL-B73
TF-DHS5	TEL-B23	TEL-B73	TF-EV110	TEL-B25	TEL-B75	TF-FK30	TEL-B23	TEL-B73
TF-DHW1	TEL-B23	TEL-B73	TF-EV120	TEL-B25	TEL-B75	TF-FK32	TEL-B23	TEL-B73
TF-DHW3	TEL-B23	TEL-B73	TF-EV130	TEL-B25	TEL-B75	TF-FK50	TEL-B23	TEL-B73
TF-DHW5	TEL-B23	TEL-B73	TF-EV250D	TEL-B30	TEL-B80	TF-FK51	TEL-B23	TEL-B73
TF-DHW7	TEL-B23	TEL-B73	TF-EV253D	TEL-B30	TEL-B80	TF-FK52	TEL-B23	TEL-B73
TF-DHW8	TEL-B23	TEL-B73	TF-EV254D	TEL-B30	TEL-B80	TF-FK60	TEL-B23	TEL-B73
TF-DHW33	TEL-B23	TEL-B73	TF-EV300	TEL-B25	TEL-B75	TF-FK61	TEL-B23	TEL-B73
TF-DHW73	TEL-B23	TEL-B73	TF-EV350D	TEL-B30	TEL-B80	TF-FK62	TEL-B23	TEL-B73
TF-DHWS2	TEL-B23	TEL-B73	TF-EV353D	TEL-B30	TEL-B80	TF-FK107	TEL-B23	TEL-B73
TF-DHWS3	TEL-B23	TEL-B73	TF-EV354D	TEL-B30	TEL-B80	TF-FN2000	TEL-B30	TEL-B80
TF-DK110	TEL-B30	TEL-B80	TF-EV550D	TEL-B30	TEL-B80	TF-FN2005	TEL-B30	TEL-B80
TF-DK115	TEL-B30	TEL-B80	TF-EVH30	TEL-B23	TEL-B73	TF-FN2007	TEL-B30	TEL-B80

本体型番
シャープ
ソニー
日立
パナソニック
パイオニア
サンヨー
NTT
ユニデン
ブラザー
キヤノン
東芝
NEC

本体型番
シャープ
ソニー
日立
パナソニック
パイオニア
サンヨー
NTT
ユニデン
ブラザー
キヤノン
東芝
NEC

パイオニア

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
TF-FN2010KT	TEL-B30	TEL-B80	TF-JGF5	TEL-B25	TEL-B75	TF-JP50	TEL-B23	TEL-B73
TF-FN2020	TEL-B30	TEL-B80	TF-JGF55	TEL-B25	TEL-B75	TF-JP55	TEL-B23	TEL-B73
TF-FN2025	TEL-B30	TEL-B80	TF-JGH103	TEL-B23	TEL-B73	TF-JP100	TEL-B23	TEL-B73
TF-FN2027	TEL-B30	TEL-B80	TF-JGH303	TEL-B23	TEL-B73	TF-JP103	TEL-B23	TEL-B73
TF-FN2030	TEL-B30	TEL-B80	TF-JGH304	TEL-B23	TEL-B73	TF-JP303	TEL-B23	TEL-B73
TF-FS12	TEL-B25	TEL-B75	TF-JGH703	TEL-B23	TEL-B73	TF-JPS1	TEL-B23	TEL-B73
TF-FS22M	TEL-B25	TEL-B75	TF-JGH704	TEL-B23	TEL-B73	TF-JPS11	TEL-B23	TEL-B73
TF-FS55M	TEL-B25	TEL-B75	TF-JGS31	TEL-B25	TEL-B75	TF-JPW2	TEL-B23	TEL-B73
TF-FV11	TEL-B23	TEL-B73	TF-JGS32	TEL-B25	TEL-B75	TF-JS1	TEL-B23	TEL-B73
TF-FV11-HS	TEL-B34	TEL-B84	TF-JGS33	TEL-B25	TEL-B75	TF-JS3	TEL-B23	TEL-B73
TF-FV12	TEL-B23	TEL-B73	TF-JGS71L	TEL-B25	TEL-B75	TF-JS50	TEL-B23	TEL-B73
TF-FV13	TEL-B23	TEL-B73	TF-JGS72L	TEL-B25	TEL-B75	TF-JS55	TEL-B23	TEL-B73
TF-FV220	TEL-B25	TEL-B75	TF-JGS73L	TEL-B25	TEL-B75	TF-JT33	TEL-B23	TEL-B73
TF-FV222	TEL-B25	TEL-B75	TF-JGS311	TEL-B25	TEL-B75	TF-JT55	TEL-B23	TEL-B73
TF-FV225KT	TEL-B25	TEL-B75	TF-JGS312	TEL-B25	TEL-B75	TF-JW30	TEL-B23	TEL-B73
TF-FV3000	TEL-B30	TEL-B80	TF-JGS313	TEL-B25	TEL-B75	TF-JW33	TEL-B23	TEL-B73
TF-FV3005	TEL-B30	TEL-B80	TF-JGV1	TEL-B23	TEL-B73	TF-JW50	TEL-B23	TEL-B73
TF-FV3020	TEL-B30	TEL-B80	TF-JGV3	TEL-B23	TEL-B73	TF-JW55	TEL-B23	TEL-B73
TF-FV3025	TEL-B30	TEL-B80	TF-JGV7	TEL-B23	TEL-B73	TF-JW70	TEL-B23	TEL-B73
TF-FV7000	TEL-B30	TEL-B80	TF-JGV13	TEL-B23	TEL-B73	TF-JW77	TEL-B23	TEL-B73
TF-FV7020	TEL-B30	TEL-B80	TF-JGV21	TEL-B25	TEL-B75	TF-JWS1	TEL-B23	TEL-B73
TF-FV7030	TEL-B30	TEL-B80	TF-JGV22	TEL-B25	TEL-B75	TF-JWS11	TEL-B23	TEL-B73
TF-FV8000	TEL-B30	TEL-B80	TF-JGV33	TEL-B23	TEL-B73	TF-K1	TEL-B23	TEL-B73
TF-FV8005	TEL-B30	TEL-B80	TF-JGV33L	TEL-B23	TEL-B73	TF-K2	TEL-B23	TEL-B73
TF-FV8020	TEL-B30	TEL-B80	TF-JGV34	TEL-B23	TEL-B73	TF-K70	TEL-B23	TEL-B73
TF-FV8025	TEL-B30	TEL-B80	TF-JGV73	TEL-B23	TEL-B73	TF-K203	TEL-B23	TEL-B73
TF-FV8030	TEL-B30	TEL-B80	TF-JGV74	TEL-B23	TEL-B73	TF-K703	TEL-B23	TEL-B73
TF-GV22	TEL-B23	TEL-B73	TF-JGV77L	TEL-B23	TEL-B73	TF-KJ204	TEL-B23	TEL-B73
TF-GVH23	TEL-B23	TEL-B73	TF-JGV212	TEL-B25	TEL-B75	TF-KJ704	TEL-B23	TEL-B73
TF-GVH24	TEL-B23	TEL-B73	TF-JGV222	TEL-B25	TEL-B75	TF-KM1	TEL-B23	TEL-B73
TF-HD5000	TEL-B30	TEL-B80	TF-JGV303L	TEL-B23	TEL-B73	TF-KM103	TEL-B23	TEL-B73
TF-HD5030	TEL-B30	TEL-B80	TF-JGV304L	TEL-B23	TEL-B73	TF-KM104	TEL-B23	TEL-B73
TF-JD1300	TEL-B30	TEL-B80	TF-JGV511	TEL-B25	TEL-B75	TF-KM105	TEL-B23	TEL-B73
TF-JD1330	TEL-B30	TEL-B80	TF-JGV512	TEL-B25	TEL-B75	TF-KVH33	TEL-B23	TEL-B73
TF-JD1340	TEL-B30	TEL-B80	TF-JGV513	TEL-B25	TEL-B75	TF-KVH34	TEL-B23	TEL-B73
TF-JF1	TEL-B23	TEL-B73	TF-JGV703L	TEL-B23	TEL-B73	TF-KVH44	TEL-B23	TEL-B73
TF-JF5	TEL-B23	TEL-B73	TF-JGV704L	TEL-B23	TEL-B73	TF-KVH45	TEL-B23	TEL-B73
TF-JF70	TEL-B23	TEL-B73	TF-JGW3	TEL-B23	TEL-B73	TF-KVH55	TEL-B23	TEL-B73
TF-JF77	TEL-B23	TEL-B73	TF-JGW7	TEL-B23	TEL-B73	TF-KVH56	TEL-B23	TEL-B73
TF-JF503	TEL-B23	TEL-B73	TF-JGW20	TEL-B23	TEL-B73	TF-KZ2000	TEL-B23	TEL-B73
TF-JG3	TEL-B23	TEL-B73	TF-JGW40	TEL-B23	TEL-B73	TF-KZ2200	TEL-B23	TEL-B73
TF-JG5	TEL-B23	TEL-B73	TF-JGY10	TEL-B23	TEL-B73	TF-KZ2300	TEL-B25	TEL-B75
TF-JG7	TEL-B23	TEL-B73	TF-JH5	TEL-B23	TEL-B73	TF-KZ2500	TEL-B25	TEL-B75
TF-JG11	TEL-B23	TEL-B73	TF-JH55	TEL-B23	TEL-B73	TF-KZ2600	TEL-B30	TEL-B80
TF-JG20	TEL-B23	TEL-B73	TF-JP1	TEL-B23	TEL-B73	TF-KZ2700	TEL-B30	TEL-B80
TF-JG30	TEL-B23	TEL-B73	TF-JP2	TEL-B23	TEL-B73	TF-KZ3000	TEL-B23	TEL-B73
TF-JG33	TEL-B23	TEL-B73	TF-JP3	TEL-B23	TEL-B73	TF-KZ3300	TEL-B23	TEL-B73
TF-JG40	TEL-B23	TEL-B73	TF-JP30	TEL-B23	TEL-B73	TF-KZ3400	TEL-B25	TEL-B75
TF-JG77	TEL-B23	TEL-B73	TF-JP33	TEL-B23	TEL-B73	TF-KZ3600	TEL-B25	TEL-B75

パイオニア

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
TF-KZ3700	TEL-B30	TEL-B80	TF-SD7240	TEL-B30	TEL-B80	TF-TK123	TEL-B25	TEL-B75
TF-KZ3800	TEL-B30	TEL-B80	TF-SD8200	TEL-B30	TEL-B80	TF-VD1100	TEL-B30	TEL-B80
TF-LP800F	TEL-B23	TEL-B73	TF-SD8205	TEL-B30	TEL-B80	TF-VD1130	TEL-B30	TEL-B80
TF-LP900F	TEL-B23	TEL-B73	TF-SD8230	TEL-B30	TEL-B80	TF-VD1140	TEL-B30	TEL-B80
TF-LPH803F	TEL-B23	TEL-B73	TF-SD8235	TEL-B30	TEL-B80	TF-VD1200	TEL-B30	TEL-B80
TF-LPH804F	TEL-B23	TEL-B73	TF-SD8240	TEL-B30	TEL-B80	TF-VD1230	TEL-B30	TEL-B80
TF-LS500	TEL-B23	TEL-B73	TF-SE10S	TEL-B34	TEL-B84	TF-VD1240	TEL-B30	TEL-B80
TF-LS700	TEL-B23	TEL-B73	TF-SE10T	TEL-B34	TEL-B84	TF-VD2200	TEL-B30	TEL-B80
TF-LS710	TEL-B25	TEL-B75	TF-SE10W	TEL-B34	TEL-B84	TF-VD2230	TEL-B30	TEL-B80
TF-LSH503	TEL-B23	TEL-B73	TF-SE15S	TEL-B34	TEL-B84	TF-VD2240	TEL-B30	TEL-B80
TF-LSH504	TEL-B23	TEL-B73	TF-SE15T	TEL-B34	TEL-B84	TF-VR20SE9	TEL-B34	TEL-B84
TF-LSH703	TEL-B23	TEL-B73	TF-SE15W	TEL-B34	TEL-B84	TF-VR20WE9	TEL-B34	TEL-B84
TF-LSH704	TEL-B23	TEL-B73	TF-SE16S	TEL-B34	TEL-B84	TF-VR50SE9	TEL-B34	TEL-B84
TF-LSH713	TEL-B25	TEL-B75	TF-SE16T	TEL-B34	TEL-B84	TF-VR50WE9	TEL-B34	TEL-B84
TF-LSH714	TEL-B25	TEL-B75	TF-SE16W	TEL-B34	TEL-B84	TF-VR80SE1	TEL-B34	TEL-B84
TF-LV52	TEL-B23	TEL-B73	TF-SF40	TEL-B23	TEL-B73	TF-VR80WE1	TEL-B34	TEL-B84
TF-LV53	TEL-B23	TEL-B73	TF-SK400	TEL-B23	TEL-B73	TF-VR85SE	TEL-B34	TEL-B84
TF-LV54	TEL-B23	TEL-B73	TF-SV520	TEL-B25	TEL-B75	TF-VR85WE	TEL-B34	TEL-B84
TF-LVH53	TEL-B23	TEL-B73	TF-SV530	TEL-B25	TEL-B75	TF-VR120E6	TEL-B30	TEL-B80
TF-LVH54	TEL-B23	TEL-B73	TF-SVH523	TEL-B25	TEL-B75	TF-VR123E6	TEL-B30	TEL-B80
TF-NV12	TEL-B23	TEL-B73	TF-SVH524	TEL-B25	TEL-B75	TF-VR320	TEL-B23	TEL-B73
TF-NV13	TEL-B23	TEL-B73	TF-SVH533	TEL-B25	TEL-B75	TF-VR350E2	TEL-B25	TEL-B75
TF-SA10S	TEL-B34	TEL-B84	TF-SVH534	TEL-B25	TEL-B75	TF-VR370E5	TEL-B30	TEL-B80
TF-SA10T	TEL-B34	TEL-B84	TF-SZ16S	TEL-B34	TEL-B84	TF-VR550	TEL-B25	TEL-B75
TF-SA10W	TEL-B34	TEL-B84	TF-SZ16W	TEL-B34	TEL-B84	TF-VRH320	TEL-B23	TEL-B73
TF-SA15S	TEL-B34	TEL-B84	TF-T500	TEL-B23	TEL-B73	TF-VRH330	TEL-B23	TEL-B73
TF-SA15T	TEL-B34	TEL-B84	TF-TA61RW	TEL-B30	TEL-B80	TF-VRH360E2	TEL-B25	TEL-B75
TF-SA15W	TEL-B34	TEL-B84	TF-TK70	TEL-B23	TEL-B73	TF-VRH560	TEL-B25	TEL-B75
TF-SA16S	TEL-B34	TEL-B84	TF-TK71	TEL-B23	TEL-B73	TF-VRT380E5	TEL-B30	TEL-B80
TF-SA16T	TEL-B34	TEL-B84	TF-TK72	TEL-B23	TEL-B73			
TF-SA16W	TEL-B34	TEL-B84	TF-TK73	TEL-B23	TEL-B73			
TF-SA30S	TEL-B34	TEL-B84	TF-TK76	TEL-B23	TEL-B73			
TF-SA30T	TEL-B34	TEL-B84	TF-TK77	TEL-B23	TEL-B73			
TF-SA30W	TEL-B34	TEL-B84	TF-TK80	TEL-B23	TEL-B73			
TF-SA70S	TEL-B34	TEL-B84	TF-TK81	TEL-B23	TEL-B73			
TF-SA70T	TEL-B34	TEL-B84	TF-TK82	TEL-B23	TEL-B73			
TF-SA70W	TEL-B34	TEL-B84	TF-TK83	TEL-B23	TEL-B73			
TF-SA75S	TEL-B34	TEL-B84	TF-TK84	TEL-B23	TEL-B73			
TF-SA75T	TEL-B34	TEL-B84	TF-TK85	TEL-B23	TEL-B73			
TF-SA75W	TEL-B34	TEL-B84	TF-TK91-WP	TEL-B23	TEL-B73			
TF-SD10S	TEL-B34	TEL-B84	TF-TK92F	TEL-B23	TEL-B73			
TF-SD10W	TEL-B34	TEL-B84	TF-TK95	TEL-B25	TEL-B75			
TF-SD15S	TEL-B34	TEL-B84	TF-TK101	TEL-B25	TEL-B75			
TF-SD15W	TEL-B34	TEL-B84	TF-TK103	TEL-B25	TEL-B75			
TF-SD1700	TEL-B30	TEL-B80	TF-TK105	TEL-B25	TEL-B75			
TF-SD1730	TEL-B30	TEL-B80	TF-TK111	TEL-B25	TEL-B75			
TF-SD1740	TEL-B30	TEL-B80	TF-TK113	TEL-B25	TEL-B75			
TF-SD200	TEL-B30	TEL-B80	TF-TK115	TEL-B25	TEL-B75			
TF-SD2230	TEL-B30	TEL-B80	TF-TK121	TEL-B25	TEL-B75			

本体型番
適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニデン

ブラザー

キヤノン

東芝

NEC

本体型番
適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニデン

ブラザー

キヤノン

東芝

NEC

サンヨー

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
FXP-60CL	TEL-B24	TEL-B74	SFX-F2CL	TEL-B24	TEL-B74	SFX-PW60	TEL-B24	TEL-B74
FXP-61CL	TEL-B24	TEL-B74	SFX-HP33WCL	TEL-B24	TEL-B74	SFX-S1CL	TEL-B24	TEL-B74
FXP-71CL	TEL-B24	TEL-B74	SFX-HPK400	TEL-B24	TEL-B74	SFX-S2CL	TEL-B24	TEL-B74
FXP-73CL	TEL-B24	TEL-B74	SFX-HPW40	TEL-B24	TEL-B74	SFX-S7CL	TEL-B24	TEL-B74
FXP-81CL	TEL-B24	TEL-B74	SFX-HPW41	TEL-B24	TEL-B74	SFX-V350	TEL-B24	TEL-B74
FXP-82CL	TEL-B24	TEL-B74	SFX-HPW70	TEL-B24	TEL-B74	SFX-V350W	TEL-B24	TEL-B74
FXP-83CL	TEL-B24	TEL-B74	SFX-K1CL	TEL-B24	TEL-B74	TEL-A1	TEL-B24	TEL-B74
FXP-87CL	TEL-B24	TEL-B74	SFX-K1VWCL	TEL-B24	TEL-B74	TEL-A2	TEL-B24	TEL-B74
FXP-L780S	TEL-B24	TEL-B74	SFX-K11	TEL-B24	TEL-B74	TEL-A3	TEL-B24	TEL-B74
FXP-P90CL	TEL-B24	TEL-B74	SFX-K12	TEL-B24	TEL-B74	TEL-A5	TEL-B24	TEL-B74
SFX-50CL	TEL-B24	TEL-B74	SFX-KT2CL	TEL-B24	TEL-B74	TEL-A6	TEL-B24	TEL-B74
SFX-55CL	TEL-B24	TEL-B74	SFX-LP60	TEL-B24	TEL-B74	TEL-A7	TEL-B24	TEL-B74
SFX-60CL	TEL-B24	TEL-B74	SFX-LP60AS	TEL-B24	TEL-B74	TEL-AD1	TEL-B24	TEL-B74
SFX-60CLW	TEL-B24	TEL-B74	SFX-NDL21	TEL-B24	TEL-B74	TEL-AT1	TEL-B24	TEL-B74
SFX-61CL	TEL-B24	TEL-B74	SFX-P3CL	TEL-B24	TEL-B74	TEL-AT2	TEL-B24	TEL-B74
SFX-61CLW	TEL-B24	TEL-B74	SFX-P3WCL	TEL-B24	TEL-B74	TEL-AW1	TEL-B24	TEL-B74
SFX-70CL	TEL-B24	TEL-B74	SFX-P10CL	TEL-B24	TEL-B74	TEL-AW2	TEL-B24	TEL-B74
SFX-71CL	TEL-B24	TEL-B74	SFX-P11	TEL-B24	TEL-B74	TEL-AW3	TEL-B24	TEL-B74
SFX-72CL	TEL-B24	TEL-B74	SFX-P15	TEL-B24	TEL-B74	TEL-AW5	TEL-B24	TEL-B74
SFX-73CL	TEL-B24	TEL-B74	SFX-P16	TEL-B24	TEL-B74	TEL-AW6	TEL-B24	TEL-B74
SFX-81CL	TEL-B24	TEL-B74	SFX-P27	TEL-B24	TEL-B74	TEL-AW8	TEL-B24	TEL-B74
SFX-82CL	TEL-B24	TEL-B74	SFX-P31CL	TEL-B24	TEL-B74	TEL-B4	TEL-B24	TEL-B74
SFX-83CL	TEL-B24	TEL-B74	SFX-P32CL	TEL-B24	TEL-B74	TEL-B5	TEL-B24	TEL-B74
SFX-85CL	TEL-B24	TEL-B74	SFX-P32WCL	TEL-B24	TEL-B74	TEL-B7	TEL-B24	TEL-B74
SFX-87CL	TEL-B24	TEL-B74	SFX-P33CL	TEL-B24	TEL-B74	TEL-BF4	TEL-B24	TEL-B74
SFX-500CL	TEL-B24	TEL-B74	SFX-P34CL	TEL-B24	TEL-B74	TEL-BW4	TEL-B24	TEL-B74
SFX-800CL	TEL-B24	TEL-B74	SFX-P35	TEL-B24	TEL-B74	TEL-BW5	TEL-B24	TEL-B74
SFX-BP505	TEL-B24	TEL-B74	SFX-P35W	TEL-B24	TEL-B74	TEL-C5	TEL-B24	TEL-B74
SFX-C2WCL	TEL-B24	TEL-B74	SFX-P36	TEL-B24	TEL-B74	TEL-CW5	TEL-B24	TEL-B74
SFX-CLK66	TEL-B24	TEL-B74	SFX-P37	TEL-B24	TEL-B74	TEL-D5	TEL-B24	TEL-B74
SFX-CLK77	TEL-B24	TEL-B74	SFX-P50CL	TEL-B24	TEL-B74	TEL-D7	TEL-B24	TEL-B74
SFX-D30E5	TEL-B36	TEL-B86	SFX-P75CL	TEL-B24	TEL-B74	TEL-DG7	TEL-B36	TEL-B86
SFX-D31E6	TEL-B36	TEL-B86	SFX-P77CL	TEL-B24	TEL-B74	TEL-DGW7	TEL-B36	TEL-B86
SFX-D38	TEL-B36	TEL-B86	SFX-P86CL	TEL-B24	TEL-B74	TEL-DH3	TEL-B36	TEL-B86
SFX-D200	TEL-B36	TEL-B86	SFX-P90CL	TEL-B24	TEL-B74	TEL-DH4	TEL-B36	TEL-B86
SFX-D210	TEL-B36	TEL-B86	SFX-P110	TEL-B24	TEL-B74	TEL-DH5	TEL-B36	TEL-B86
SFX-D500	TEL-B36	TEL-B86	SFX-P150	TEL-B24	TEL-B74	TEL-DHW3	TEL-B36	TEL-B86
SFX-DK13	TEL-B36	TEL-B86	SFX-P160	TEL-B24	TEL-B74	TEL-DHW4	TEL-B36	TEL-B86
SFX-DT71	TEL-B36	TEL-B86	SFX-P270	TEL-B24	TEL-B74	TEL-DHW5	TEL-B36	TEL-B86
SFX-DT700	TEL-B36	TEL-B86	SFX-P360	TEL-B24	TEL-B74	TEL-DJ2	TEL-B36	TEL-B86
SFX-DT710	TEL-B36	TEL-B86	SFX-P370	TEL-B24	TEL-B74	TEL-DJ3	TEL-B36	TEL-B86
SFX-DW38	TEL-B36	TEL-B86	SFX-PK1CL	TEL-B24	TEL-B74	TEL-DJ4	TEL-B36	TEL-B86
SFX-DW71	TEL-B36	TEL-B86	SFX-PK1TCL	TEL-B24	TEL-B74	TEL-DJ5	TEL-B36	TEL-B86
SFX-DW200	TEL-B36	TEL-B86	SFX-PK1WCL	TEL-B24	TEL-B74	TEL-DJ8	TEL-B36	TEL-B86
SFX-DW210	TEL-B36	TEL-B86	SFX-PK100	TEL-B24	TEL-B74	TEL-DJT9	TEL-B36	TEL-B86
SFX-DW500	TEL-B36	TEL-B86	SFX-PS15	TEL-B24	TEL-B74	TEL-DJW2	TEL-B36	TEL-B86
SFX-DW700	TEL-B36	TEL-B86	SFX-PS60	TEL-B24	TEL-B74	TEL-DJW4	TEL-B36	TEL-B86
SFX-DW710	TEL-B36	TEL-B86	SFX-PW15	TEL-B24	TEL-B74	TEL-DJW5	TEL-B36	TEL-B86
SFX-F1CL	TEL-B24	TEL-B74	SFX-PW16	TEL-B24	TEL-B74	TEL-DJW6	TEL-B36	TEL-B86

サンヨー

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
TEL-DJW8	TEL-B36	TEL-B86	TEL-L310	TEL-B24	TEL-B74	TEL-LK78	TEL-B24	TEL-B74
TEL-DJW9	TEL-B36	TEL-B86	TEL-L311	TEL-B24	TEL-B74	TEL-LK770	TEL-B24	TEL-B74
TEL-DW5	TEL-B24	TEL-B74	TEL-L320	TEL-B24	TEL-B74	TEL-LN5	TEL-B24	TEL-B74
TEL-E3	TEL-B24	TEL-B74	TEL-L321	TEL-B24	TEL-B74	TEL-LV77	TEL-B24	TEL-B74
TEL-E5	TEL-B24	TEL-B74	TEL-L350	TEL-B24	TEL-B74	TEL-LVW77	TEL-B24	TEL-B74
TEL-E6	TEL-B24	TEL-B74	TEL-L351	TEL-B24	TEL-B74	TEL-LW50	TEL-B24	TEL-B74
TEL-E7	TEL-B24	TEL-B74	TEL-L352	TEL-B24	TEL-B74	TEL-LW51	TEL-B24	TEL-B74
TEL-EW5	TEL-B24	TEL-B74	TEL-L360	TEL-B24	TEL-B74	TEL-LW60	TEL-B24	TEL-B74
TEL-EW6	TEL-B24	TEL-B74	TEL-L361	TEL-B24	TEL-B74	TEL-LW61	TEL-B24	TEL-B74
TEL-EW7	TEL-B24	TEL-B74	TEL-L371	TEL-B24	TEL-B74	TEL-LW70	TEL-B24	TEL-B74
TEL-F3	TEL-B24	TEL-B74	TEL-L381	TEL-B24	TEL-B74	TEL-LW71	TEL-B24	TEL-B74
TEL-F4	TEL-B24	TEL-B74	TEL-L500	TEL-B24	TEL-B74	TEL-LW75	TEL-B24	TEL-B74
TEL-F5	TEL-B24	TEL-B74	TEL-L510	TEL-B24	TEL-B74	TEL-LW77	TEL-B24	TEL-B74
TEL-FW4	TEL-B24	TEL-B74	TEL-L701	TEL-B24	TEL-B74	TEL-LW500	TEL-B24	TEL-B74
TEL-FW5	TEL-B24	TEL-B74	TEL-L702	TEL-B24	TEL-B74	TEL-LW510	TEL-B24	TEL-B74
TEL-G3	TEL-B24	TEL-B74	TEL-L710	TEL-B24	TEL-B74	TEL-LW713	TEL-B24	TEL-B74
TEL-G4	TEL-B24	TEL-B74	TEL-L710S	TEL-B24	TEL-B74	TEL-LW733	TEL-B24	TEL-B74
TEL-GW4	TEL-B24	TEL-B74	TEL-L711	TEL-B24	TEL-B74	TEL-SA7	TEL-B24	TEL-B74
TEL-HA5	TEL-B24	TEL-B74	TEL-L712	TEL-B24	TEL-B74	TEL-SDG7	TEL-B36	TEL-B86
TEL-HA5S	TEL-B24	TEL-B74	TEL-L713	TEL-B24	TEL-B74	TEL-SDH4	TEL-B36	TEL-B86
TEL-HA6	TEL-B24	TEL-B74	TEL-L713S	TEL-B24	TEL-B74	TEL-SDH5	TEL-B36	TEL-B86
TEL-HA6S	TEL-B24	TEL-B74	TEL-L720	TEL-B24	TEL-B74	TEL-SDJ2	TEL-B36	TEL-B86
TEL-HA7	TEL-B24	TEL-B74	TEL-L720S	TEL-B24	TEL-B74	TEL-SDJ4	TEL-B36	TEL-B86
TEL-HA7S	TEL-B24	TEL-B74	TEL-L721	TEL-B24	TEL-B74	TEL-SDJ5	TEL-B36	TEL-B86
TEL-HA8	TEL-B24	TEL-B74	TEL-L730	TEL-B24	TEL-B74	TEL-SDJ8	TEL-B36	TEL-B86
TEL-HA8S	TEL-B24	TEL-B74	TEL-L730S	TEL-B24	TEL-B74	TEL-SE5	TEL-B24	TEL-B74
TEL-HBT7	TEL-B24	TEL-B74	TEL-L731	TEL-B24	TEL-B74	TEL-SE6	TEL-B24	TEL-B74
TEL-HBW7	TEL-B24	TEL-B74	TEL-L731S	TEL-B24	TEL-B74	TEL-SF5	TEL-B24	TEL-B74
TEL-HF8	TEL-B24	TEL-B74	TEL-L733	TEL-B24	TEL-B74	TEL-SF8	TEL-B24	TEL-B74
TEL-HF80	TEL-B24	TEL-B74	TEL-L733S	TEL-B24	TEL-B74	TEL-SG4	TEL-B24	TEL-B74
TEL-HK1	TEL-B24	TEL-B74	TEL-L760	TEL-B24	TEL-B74	TEL-SK1	TEL-B24	TEL-B74
TEL-KK1	TEL-B24	TEL-B74	TEL-L760S	TEL-B24	TEL-B74	TEL-SLAN60	TEL-B36	TEL-B86
TEL-KK2	TEL-B24	TEL-B74	TEL-L772	TEL-B24	TEL-B74	TEL-SP33	TEL-B24	TEL-B74
TEL-KK3	TEL-B24	TEL-B74	TEL-L773	TEL-B24	TEL-B74	TEL-SP35	TEL-B24	TEL-B74
TEL-KK4	TEL-B24	TEL-B74	TEL-L775	TEL-B24	TEL-B74	TEL-SP40	TEL-B24	TEL-B74
TEL-L10	TEL-B24	TEL-B74	TEL-L776	TEL-B24	TEL-B74	TEL-SP41	TEL-B24	TEL-B74
TEL-L10S	TEL-B24	TEL-B74	TEL-L777	TEL-B24	TEL-B74	TEL-SP60	TEL-B24	TEL-B74
TEL-L30	TEL-B24	TEL-B74	TEL-L780	TEL-B24	TEL-B74	TEL-SP70	TEL-B24	TEL-B74
TEL-L30S	TEL-B24	TEL-B74	TEL-L780S	TEL-B24	TEL-B74	TEL-V21	TEL-B24	TEL-B74
TEL-L31	TEL-B24	TEL-B74	TEL-L781	TEL-B24	TEL-B74	TEL-V50	TEL-B24	TEL-B74
TEL-L31S	TEL-B24	TEL-B74	TEL-L781S	TEL-B24	TEL-B74	TEL-V60	TEL-B24	TEL-B74
TEL-L50	TEL-B24	TEL-B74	TEL-L783	TEL-B24	TEL-B74	TEL-VV21	TEL-B24	TEL-B74
TEL-L51	TEL-B24	TEL-B74	TEL-L783S	TEL-B24	TEL-B74			
TEL-L60	TEL-B24	TEL-B74	TEL-LAN60	TEL-B36	TEL-B86			
TEL-L61	TEL-B24	TEL-B74	TEL-LANT60	TEL-B36	TEL-B86			
TEL-L61S	TEL-B24	TEL-B74	TEL-LANW60	TEL-B36	TEL-B86			
TEL-L70	TEL-B24	TEL-B74	TEL-LG37	TEL-B24	TEL-B74			
TEL-L70S	TEL-B24	TEL-B74	TEL-LGW37	TEL-B24	TEL-B74			
TEL-L71	TEL-B24	TEL-B74	TEL-LK77	TEL-B24	TEL-B74			

本体型番
適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニオン

ブラザー

キヤノン

東芝

NEC

本体型番
適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニオン

ブラザー

キヤノン

東芝

NEC

NTT

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CP-561L	TEL-B25	TEL-B75	i・トレンビ-W-1000P	TEL-B29	TEL-B79	P-721NDw	TEL-B35	TEL-B85
CP-561Lw	TEL-B25	TEL-B75	i・トレンビ-W-1100P	TEL-B29	TEL-B79	P-722PD	TEL-B38	TEL-B88
CP-562L	TEL-B25	TEL-B75	i・トレンビ-W-1200LP	TEL-B29	TEL-B79	P-722PDw	TEL-B38	TEL-B88
CP-562Lw	TEL-B25	TEL-B75	i・トレンビ-W-1200T	TEL-B29	TEL-B79	P-730LD	TEL-B29	TEL-B79
CP-563L	TEL-B25	TEL-B75	i・トレンビ-ファクス3000S		TEL-B71	P-750LD	TEL-B29	TEL-B79
CP-563Lw	TEL-B25	TEL-B75	i・トレンビ-ファクス3100LS (デジタルコードレス電話機LS1用)	TEL-B29	TEL-B79	P-752LC	TEL-B25	TEL-B75
CP-570LC	TEL-B22	TEL-B72				P-753LC	TEL-B25	TEL-B75
CP-570LCw	TEL-B22	TEL-B72	i・トレンビ-ファクス3100LS (デジタルコードレス電話機S3用)		TEL-B71	P-754LC	TEL-B28	TEL-B78
CP-571LC	TEL-B25	TEL-B75	JC-260CL	TEL-B26	TEL-B76	P-755LC	TEL-B22	TEL-B72
CP-571LCw	TEL-B25	TEL-B75	JC-761LC	TEL-B33	TEL-B83	P-756LC	TEL-B22	TEL-B72
CP-572LC	TEL-B25	TEL-B75	JC-762CL	TEL-B33	TEL-B83	P-757LD	TEL-B31	TEL-B81
CP-572LCw	TEL-B25	TEL-B75	MF30CL	TEL-B33	TEL-B83	P-757LDII	TEL-B31	TEL-B81
CP-573LC	TEL-B25	TEL-B75	MF30CW	TEL-B33	TEL-B83	P-757LDIII	TEL-B31	TEL-B81
CP-573LCw	TEL-B25	TEL-B75	MF70CL	TEL-B29	TEL-B79	P-757LDw	TEL-B31	TEL-B81
DC-100I	TEL-B30	TEL-B80	MF70CW	TEL-B29	TEL-B79	P-757LDwII	TEL-B31	TEL-B81
DC-100Iw	TEL-B30	TEL-B80	P-262DCL	TEL-B31	TEL-B81	P-757LDwIII	TEL-B31	TEL-B81
DCP-300i	TEL-B30	TEL-B80	P-262DCLw	TEL-B31	TEL-B81	P-758LC	TEL-B33	TEL-B83
DCP-300iw	TEL-B30	TEL-B80	P-263CL	TEL-B33	TEL-B83	P-758LCw	TEL-B33	TEL-B83
DCP-550L	TEL-B29	TEL-B79	P-263CLw	TEL-B33	TEL-B83	P-759LC	TEL-B33	TEL-B83
DCP-550Lw	TEL-B29	TEL-B79	P-264DCL		TEL-B82	P-759LCw	TEL-B33	TEL-B83
DCP-560L	TEL-B29	TEL-B79	P-264DCLw		TEL-B82	P-760LC	TEL-B25	TEL-B75
DCP-560Lw	TEL-B29	TEL-B79	P-265DCL	TEL-B29	TEL-B79	P-770BLC	TEL-B25	TEL-B75
DCP-4200	TEL-B29	TEL-B79	P-265DCLw	TEL-B29	TEL-B79	P-771BLC	TEL-B25	TEL-B75
DCP-4200w	TEL-B29	TEL-B79	P-266PD	TEL-B37	TEL-B87	P-771BLCII	TEL-B25	TEL-B75
DCP-4300	TEL-B29	TEL-B79	P-266PDw	TEL-B37	TEL-B87	T-22CL	TEL-B26	TEL-B76
DCP-4300w	TEL-B29	TEL-B79	P-266SD	TEL-B29	TEL-B79	T-214CL	TEL-B26	TEL-B76
DCP-4400	TEL-B29	TEL-B79	P-266SDw	TEL-B29	TEL-B79	T-215CL	TEL-B26	TEL-B76
DCP-4400w	TEL-B29	TEL-B79	P-267PD	TEL-B37	TEL-B87	T-217CL	TEL-B26	TEL-B76
DCP-5000	TEL-B31	TEL-B81	P-267PDw	TEL-B37	TEL-B87	T-218CL	TEL-B26	TEL-B76
DCP-5000II	TEL-B31	TEL-B81	P-267SD	TEL-B29	TEL-B79	T-219CL	TEL-B26	TEL-B76
DCP-5000w	TEL-B31	TEL-B81	P-267SDw	TEL-B29	TEL-B79	T-220CL	TEL-B26	TEL-B76
DCP-5000wII	TEL-B31	TEL-B81	P-268SD	TEL-B29	TEL-B79	T-221CL	TEL-B26	TEL-B76
DCP-5100	TEL-B31	TEL-B81	P-268SDw	TEL-B29	TEL-B79	T-240CL	TEL-B26	TEL-B76
DCP-5100w	TEL-B31	TEL-B81	P-710LC	TEL-B25	TEL-B75	T-241DCL	TEL-B29	TEL-B79
DCP-5200	TEL-B30	TEL-B80	P-711LC	TEL-B25	TEL-B75	T-241DCLw	TEL-B29	TEL-B79
DCP-5200w	TEL-B30	TEL-B80	P-712LC	TEL-B25	TEL-B75	T-242CL	TEL-B26	TEL-B76
DCP-5300		TEL-B82	P-713LC	TEL-B33	TEL-B83	T-243DCL	TEL-B29	TEL-B79
DCP-5300W		TEL-B82	P-713LCw	TEL-B33	TEL-B83	T-243DCLw	TEL-B29	TEL-B79
DCP-5400		TEL-B82	P-714LC	TEL-B33	TEL-B83	T-244DCL		TEL-B71
DCP-5400W		TEL-B82	P-715LC	TEL-B33	TEL-B83	T-244DCLw		TEL-B71
DCP-5500I	TEL-B30	TEL-B80	P-716LC	TEL-B33	TEL-B83	T-245DCL		TEL-B71
DCP-5500Iw	TEL-B30	TEL-B80	P-716LCw	TEL-B33	TEL-B83	T-246DCL		TEL-B71
DCP-5500P	TEL-B37	TEL-B87	P-717LC	TEL-B33	TEL-B83	T-246DCLw		TEL-B71
DCP-5500Pw	TEL-B37	TEL-B87	P-717LCw	TEL-B33	TEL-B83	T-247DCL		TEL-B71
DCP-5600P	TEL-B37	TEL-B87	P-718LC	TEL-B33	TEL-B83	T-261DCL		TEL-B71
DCP-5600Pw	TEL-B37	TEL-B87	P-720PD		TEL-B82	T-756LCw	TEL-B22	TEL-B72
DCP-5700P	TEL-B38	TEL-B88	P-720PDw		TEL-B82	でんえもん 214CL	TEL-B26	TEL-B76
DCP-5700Pw	TEL-B38	TEL-B88	P-721ND	TEL-B35	TEL-B85	でんえもん 215CL	TEL-B26	TEL-B76
FX2-DCL	TEL-B29	TEL-B79				でんえもん 217CL	TEL-B26	TEL-B76

NTT

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
でんえもん 218CL	TEL-B26	TEL-B76	でんえもん 266PDw	TEL-B37	TEL-B87	でんえもん 750LD	TEL-B29	TEL-B79
でんえもん 219CL	TEL-B26	TEL-B76	でんえもん 266SD	TEL-B29	TEL-B79	でんえもん 752LC	TEL-B25	TEL-B75
でんえもん 220CL	TEL-B26	TEL-B76	でんえもん 266SDw	TEL-B29	TEL-B79	でんえもん 753LC	TEL-B25	TEL-B75
でんえもん 221CL	TEL-B26	TEL-B76	でんえもん 267PD	TEL-B37	TEL-B87	でんえもん 754LC	TEL-B28	TEL-B78
でんえもん 240CL	TEL-B26	TEL-B76	でんえもん 267PDw	TEL-B37	TEL-B87	でんえもん 755LC	TEL-B22	TEL-B72
でんえもん 241DCL	TEL-B29	TEL-B79	でんえもん 267SD	TEL-B29	TEL-B79	でんえもん 756LC	TEL-B22	TEL-B72
でんえもん 241DCLw	TEL-B29	TEL-B79	でんえもん 267SDw	TEL-B29	TEL-B79	でんえもん 756LCw	TEL-B22	TEL-B72
でんえもん 242CL	TEL-B26	TEL-B76	でんえもん 268SD	TEL-B29	TEL-B79	でんえもん 757LD	TEL-B31	TEL-B81
でんえもん 243DCL	TEL-B29	TEL-B79	でんえもん 268SDw	TEL-B29	TEL-B79	でんえもん 757LDII	TEL-B31	TEL-B81
でんえもん 243DCLw	TEL-B29	TEL-B79	でんえもん 710LC	TEL-B25	TEL-B75	でんえもん 757LDIII	TEL-B31	TEL-B81
でんえもん 244DCL		TEL-B71	でんえもん 711LC	TEL-B25	TEL-B75	でんえもん 757LDw	TEL-B31	TEL-B81
でんえもん 244DCLw		TEL-B71	でんえもん 712LC	TEL-B25	TEL-B75	でんえもん 757LDwII	TEL-B31	TEL-B81
でんえもん 245DCL		TEL-B71	でんえもん 713LC	TEL-B33	TEL-B83	でんえもん 757LDwIII	TEL-B31	TEL-B81
でんえもん 246DCL		TEL-B71	でんえもん 713LCw	TEL-B33	TEL-B83	でんえもん 758LC	TEL-B33	TEL-B83
でんえもん 246DCLw		TEL-B71	でんえもん 714LC	TEL-B33	TEL-B83	でんえもん 758LCw	TEL-B33	TEL-B83
でんえもん 247DCL		TEL-B71	でんえもん 715LC	TEL-B33	TEL-B83	でんえもん 759LC	TEL-B33	TEL-B83
でんえもん 261DCL		TEL-B71	でんえもん 716LC	TEL-B33	TEL-B83	でんえもん 759LCw	TEL-B33	TEL-B83
でんえもん 262DCL	TEL-B31	TEL-B81	でんえもん 716LCw	TEL-B33	TEL-B83	でんえもん 760LC	TEL-B25	TEL-B75
でんえもん 262DCLw	TEL-B31	TEL-B81	でんえもん 717LC	TEL-B33	TEL-B83	でんえもん 761LC	TEL-B33	TEL-B83
でんえもん 263CL	TEL-B33	TEL-B83	でんえもん 717LCw	TEL-B33	TEL-B83	でんえもん 762CL	TEL-B33	TEL-B83
でんえもん 263CLw	TEL-B33	TEL-B83	でんえもん 718LC	TEL-B33	TEL-B83	でんえもん 770BLC	TEL-B25	TEL-B75
でんえもん 264DCL		TEL-B82	でんえもん 720PD		TEL-B82	でんえもん 771BLC	TEL-B25	TEL-B75
でんえもん 264DCLw		TEL-B82	でんえもん 720PDw		TEL-B82	でんえもん 771BLCII	TEL-B25	TEL-B75
でんえもん 265DCL	TEL-B29	TEL-B79	でんえもん 722PD	TEL-B38	TEL-B88	パッセ R400	TEL-B26	TEL-B76
でんえもん 265DCLw	TEL-B29	TEL-B79	でんえもん 722PDw	TEL-B38	TEL-B88			
でんえもん 266PD	TEL-B37	TEL-B87	でんえもん 730LD	TEL-B29	TEL-B79			

ユニデン

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CDL1	TEL-B27	TEL-B77	DCX250	TEL-B34	TEL-B84	DECT3288	TEL-B34	TEL-B84
CDL7	TEL-B27	TEL-B77	DCX300	TEL-B34	TEL-B84	UF-60CLW	TEL-B27	TEL-B77
CDL10	TEL-B27	TEL-B77	DCX310	TEL-B34	TEL-B84	UFK2	TEL-B27	TEL-B77
CDLK1	TEL-B27	TEL-B77	DCX320	TEL-B34	TEL-B84	UX110S	TEL-B27	TEL-B77
CDLK7	TEL-B27	TEL-B77	DECT2288	TEL-B34	TEL-B84	UX120D	TEL-B27	TEL-B77
CDLK10	TEL-B27	TEL-B77	DECT2570	TEL-B34	TEL-B84	UXK1	TEL-B27	TEL-B77
CDLK-1	TEL-B27	TEL-B77	DECT2588	TEL-B34	TEL-B84	UXL50S	TEL-B27	TEL-B77
CDLK-7	TEL-B27	TEL-B77	DECT3080	TEL-B34	TEL-B84	UXL70D	TEL-B27	TEL-B77
CDLK-10	TEL-B27	TEL-B77	DECT3188C	TEL-B34	TEL-B84	UXL70DPlus	TEL-B27	TEL-B77
DCX220	TEL-B34	TEL-B84	DECT3280	TEL-B34	TEL-B84			

本体型番適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニデン

ブラザー

キヤノン

東芝

NEC

本体型番適用表

シャープ

ソニー

日立

パナソニック

パイオニア

サンヨー

NTT

ユニデン

ブラザー

キヤノン

東芝

NEC

ブラザー

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
BCL-100	TEL-B25	TEL-B75	FAX-720CLW	TEL-B25	TEL-B75	MFC-695CDN	TEL-B30	TEL-B80
BCL-200	TEL-B25	TEL-B75	FAX-730CL	TEL-B25	TEL-B75	MFC-695CDWN	TEL-B30	TEL-B80
BCL-300	TEL-B25	TEL-B75	FAX-730CLW	TEL-B25	TEL-B75	MFC-735CD	TEL-B30	TEL-B80
BCL-300D	TEL-B25	TEL-B75	FAX-750CL	TEL-B25	TEL-B75	MFC-735CDW	TEL-B30	TEL-B80
BCL-400	TEL-B25	TEL-B75	FAX-750HS	TEL-B25	TEL-B75	MFC-830CLN	TEL-B25	TEL-B75
BCL-500	TEL-B25	TEL-B75	FAX-760CL	TEL-B25	TEL-B75	MFC-830CLWN	TEL-B25	TEL-B75
BCL-500S	TEL-B25	TEL-B75	FAX-760CLT	TEL-B25	TEL-B75	MFC-840CLN	TEL-B25	TEL-B75
BCL-600	TEL-B25	TEL-B75	FAX-760HS	TEL-B25	TEL-B75	MFC-850CDN	TEL-B30	TEL-B80
BCL-600K	TEL-B25	TEL-B75	FAX-780CL	TEL-B25	TEL-B75	MFC-850CDWN	TEL-B30	TEL-B80
BCL-700SR	TEL-B25	TEL-B75	FAX-780CLW	TEL-B25	TEL-B75	MFC-860CDN	TEL-B30	TEL-B80
BCL-900	TEL-B25	TEL-B75	FAX-790CL	TEL-B25	TEL-B75	MFC-870CDN	TEL-B30	TEL-B80
BCL-D30	TEL-B30	TEL-B80	FAX-790CLW	TEL-B25	TEL-B75	MFC-870CDWN	TEL-B30	TEL-B80
BCL-D30K	TEL-B30	TEL-B80	FAX-800CL	TEL-B25	TEL-B75	MFC-880CDN	TEL-B30	TEL-B80
BCL-D40	TEL-B30	TEL-B80	FAX-800CLW	TEL-B25	TEL-B75	MFC-880CDWN	TEL-B30	TEL-B80
BCL-D50	TEL-B30	TEL-B80	FAX-900CL	TEL-B25	TEL-B75	MFC-930CDN	TEL-B30	TEL-B80
BCL-D80	TEL-B30	TEL-B80	FAX-910CL	TEL-B25	TEL-B75	MFC-930CDWN	TEL-B30	TEL-B80
BCL-D90BK	TEL-B30	TEL-B80	FAX-910CLW	TEL-B25	TEL-B75	MFC-935CDN	TEL-B30	TEL-B80
BCL-D90WH	TEL-B30	TEL-B80	FAX-920CL	TEL-B25	TEL-B75	MFC-935CDWN	TEL-B30	TEL-B80
BCL-D100WH	TEL-B30	TEL-B80	FAX-920CLW	TEL-B25	TEL-B75	MFC-J700D	TEL-B30	TEL-B80
BCL-D110BK	TEL-B30	TEL-B80	FAX-1000CL	TEL-B25	TEL-B75	MFC-J700DW	TEL-B30	TEL-B80
BCL-D110WH	TEL-B30	TEL-B80	FAX-1100CL	TEL-B25	TEL-B75	MFC-J705D	TEL-B30	TEL-B80
BCL-D120K-BK	TEL-B30	TEL-B80	FAX-1100CLW	TEL-B25	TEL-B75	MFC-J705DW	TEL-B30	TEL-B80
BCL-D120K-WH	TEL-B30	TEL-B80	FAX-1550CL	TEL-B25	TEL-B75	MFC-J710D	TEL-B30	TEL-B80
FAX-30L	TEL-B25	TEL-B75	FAX-2000CL	TEL-B25	TEL-B75	MFC-J710DW	TEL-B30	TEL-B80
FAX-105CLY	TEL-B25	TEL-B75	FAX-2100CL	TEL-B25	TEL-B75	MFC-J720D	TEL-B30	TEL-B80
FAX-170CL	TEL-B25	TEL-B75	FAX-2100CLW	TEL-B25	TEL-B75	MFC-J720DW	TEL-B30	TEL-B80
FAX-180CL	TEL-B25	TEL-B75	FAX-K78CL	TEL-B25	TEL-B75	MFC-J727D	TEL-B30	TEL-B80
FAX-190CL	TEL-B25	TEL-B75	FAX-K79CL	TEL-B25	TEL-B75	MFC-J727DW	TEL-B30	TEL-B80
FAX-200CL	TEL-B25	TEL-B75	FAX-K79CLW	TEL-B25	TEL-B75	MFC-J730D	TEL-B30	TEL-B80
FAX-300CL	TEL-B25	TEL-B75	FAX-K80CL	TEL-B25	TEL-B75	MFC-J730DWN	TEL-B30	TEL-B80
FAX-300CLW	TEL-B25	TEL-B75	FAX-KJ7CL	TEL-B25	TEL-B75	MFC-J737DN	TEL-B30	TEL-B80
FAX-310DE3	TEL-B30	TEL-B80	FAX-KJ8CL	TEL-B25	TEL-B75	MFC-J737DWN	TEL-B30	TEL-B80
FAX-310DL	TEL-B30	TEL-B80	FAX-KJ9CL	TEL-B25	TEL-B75	MFC-J800D	TEL-B30	TEL-B80
FAX-310DW	TEL-B30	TEL-B80	FAX-V6CL	TEL-B25	TEL-B75	MFC-J800DW	TEL-B30	TEL-B80
FAX-315DL	TEL-B30	TEL-B80	FAX-V6CLW	TEL-B25	TEL-B75	MFC-J805D	TEL-B30	TEL-B80
FAX-315DW	TEL-B30	TEL-B80	MFC-150CL	TEL-B25	TEL-B75	MFC-J805DW	TEL-B30	TEL-B80
FAX-320DL	TEL-B30	TEL-B80	MFC-150CLW	TEL-B25	TEL-B75	MFC-J810DN	TEL-B30	TEL-B80
FAX-320DW	TEL-B30	TEL-B80	MFC-610CLN	TEL-B25	TEL-B75	MFC-J810DWN	TEL-B30	TEL-B80
FAX-330DL	TEL-B30	TEL-B80	MFC-610CLWN	TEL-B25	TEL-B75	MFC-J820DN	TEL-B30	TEL-B80
FAX-330DW	TEL-B30	TEL-B80	MFC-615CL	TEL-B25	TEL-B75	MFC-J820DWN	TEL-B30	TEL-B80
FAX-350CL	TEL-B25	TEL-B75	MFC-620CLN	TEL-B25	TEL-B75	MFC-J827DN	TEL-B30	TEL-B80
FAX-350CLW	TEL-B25	TEL-B75	MFC-630CD	TEL-B30	TEL-B80	MFC-J827DWN	TEL-B30	TEL-B80
FAX-360DL	TEL-B30	TEL-B80	MFC-630CDW	TEL-B30	TEL-B80	MFC-J830DN	TEL-B30	TEL-B80
FAX-360DW	TEL-B30	TEL-B80	MFC-650CD	TEL-B30	TEL-B80	MFC-J830DWN	TEL-B30	TEL-B80
FAX-370DL	TEL-B30	TEL-B80	MFC-650CDW	TEL-B30	TEL-B80	MFC-J837DN	TEL-B30	TEL-B80
FAX-370DW	TEL-B30	TEL-B80	MFC-670CD	TEL-B30	TEL-B80	MFC-J837DWN	TEL-B30	TEL-B80
FAX-380DL	TEL-B30	TEL-B80	MFC-670CDW	TEL-B30	TEL-B80	MFC-J850DN	TEL-B30	TEL-B80
FAX-380DW	TEL-B30	TEL-B80	MFC-675CD	TEL-B30	TEL-B80	MFC-J850DWN	TEL-B30	TEL-B80
FAX-720CL	TEL-B25	TEL-B75	MFC-675CDW	TEL-B30	TEL-B80	MFC-J855DN	TEL-B30	TEL-B80

ブラザー

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
MFC-J855DWN	TEL-B30	TEL-B80	MFC-J907DWN	TEL-B30	TEL-B80	MFC-J987DWN	TEL-B30	TEL-B80
MFC-J860DN	TEL-B30	TEL-B80	MFC-J950DN	TEL-B30	TEL-B80	MFC-J990DN	TEL-B30	TEL-B80
MFC-J860DWN	TEL-B30	TEL-B80	MFC-J950DWN	TEL-B30	TEL-B80	MFC-J990DWN	TEL-B30	TEL-B80
MFC-J890DN	TEL-B30	TEL-B80	MFC-J955DN	TEL-B30	TEL-B80	MFC-J997DN	TEL-B30	TEL-B80
MFC-J890DWN	TEL-B30	TEL-B80	MFC-J955DWN	TEL-B30	TEL-B80	MFC-J997DWN	TEL-B30	TEL-B80
MFC-J897DN	TEL-B30	TEL-B80	MFC-J960DN	TEL-B30	TEL-B80	MFC-J5820DN	TEL-B30	TEL-B80
MFC-J897DWN	TEL-B30	TEL-B80	MFC-J960DWN	TEL-B30	TEL-B80			
MFC-J900DN	TEL-B30	TEL-B80	MFC-J980DN	TEL-B30	TEL-B80			
MFC-J900DWN	TEL-B30	TEL-B80	MFC-J980DWN	TEL-B30	TEL-B80			
MFC-J907DN	TEL-B30	TEL-B80	MFC-J987DN	TEL-B30	TEL-B80			

キヤノン

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CF-D1CL	TEL-B28	TEL-B78	CF-SL50W	TEL-B33	TEL-B83	CF-VL20	TEL-B27	TEL-B77
CF-PL90	TEL-B33	TEL-B83	CF-SL55	TEL-B33	TEL-B83	CL7	TEL-B27	TEL-B77
CF-PL90W	TEL-B33	TEL-B83	CF-SL55W	TEL-B33	TEL-B83	CL8	TEL-B27	TEL-B77
CF-PL95	TEL-B33	TEL-B83	CF-SL70	TEL-B33	TEL-B83	CL10	TEL-B33	TEL-B83
CF-PL95W	TEL-B33	TEL-B83	CF-SL75	TEL-B33	TEL-B83	CL11	TEL-B33	TEL-B83
CF-S10	TEL-B33	TEL-B83	CF-SL75W	TEL-B33	TEL-B83	CL12	TEL-B33	TEL-B83
CF-S10W	TEL-B33	TEL-B83	CF-VL1	TEL-B27	TEL-B77	CL13	TEL-B33	TEL-B83
CF-S15	TEL-B33	TEL-B83	CF-VL2W	TEL-B27	TEL-B77	DCL1	TEL-B28	TEL-B78
CF-SL50	TEL-B33	TEL-B83	CF-VL10	TEL-B27	TEL-B77			

東芝

本体型番	◎開孔型番		本体型番	◎開孔型番		本体型番	◎開孔型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CL-25K	TEL-B25	TEL-B75	CL-43K	TEL-B25	TEL-B75	PFX-27CL	TEL-B25	TEL-B75
CL-26K	TEL-B25	TEL-B75	PFX-25CL	TEL-B25	TEL-B75	PFX-43CL	TEL-B25	TEL-B75
CL-27K	TEL-B25	TEL-B75	PFX-26CLD	TEL-B25	TEL-B75			



NEC

本体型番	◎型番		本体型番	◎型番		本体型番	◎型番	
	長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ		長持ちタイプ	高容量タイプ
CL-K303	TEL-B27	TEL-B77	speax52CLW	TEL-B27	TEL-B77	SPL-S505VW	TEL-B27	TEL-B77
SP-DA120	TEL-B35	TEL-B85	speax52-ZK	TEL-B27	TEL-B77	SP-NA540	TEL-B35	TEL-B85
SP-DA120W	TEL-B35	TEL-B85	speax55CL	TEL-B27	TEL-B77	SP-NA540W	TEL-B35	TEL-B85
SP-DA220	TEL-B35	TEL-B85	speax316KCL	TEL-B27	TEL-B77	SP-NA640	TEL-B35	TEL-B85
SP-DA220W	TEL-B35	TEL-B85	speax326KCL	TEL-B27	TEL-B77	SP-P70H	TEL-B34	TEL-B84
SP-DA240	TEL-B35	TEL-B85	speax435KCL	TEL-B27	TEL-B77	SP-P70HW	TEL-B34	TEL-B84
SP-DA240W	TEL-B35	TEL-B85	speax435KCLW	TEL-B27	TEL-B77	SP-R100	TEL-B34	TEL-B84
SP-DA320	TEL-B35	TEL-B85	speax456YCL	TEL-B27	TEL-B77	SP-R100W	TEL-B34	TEL-B84
SP-DA320W	TEL-B35	TEL-B85	speax458CL	TEL-B27	TEL-B77	SP-S23	TEL-B34	TEL-B84
SP-DA340	TEL-B35	TEL-B85	speaxJ1CL	TEL-B27	TEL-B77	SP-S23W	TEL-B34	TEL-B84
SP-DA340W	TEL-B35	TEL-B85	speaxJ2CL	TEL-B27	TEL-B77	SP-S33	TEL-B34	TEL-B84
speax22CL	TEL-B27	TEL-B77	speaxJ2CLW	TEL-B27	TEL-B77	SP-S33W	TEL-B34	TEL-B84
speax22TA	TEL-B27	TEL-B77	speaxJ22CL	TEL-B27	TEL-B77	SPX-N3	TEL-B27	TEL-B77
speax23CL	TEL-B27	TEL-B77	speaxJ22D	TEL-B27	TEL-B77	SPX-N3W	TEL-B27	TEL-B77
speax23W	TEL-B27	TEL-B77	speaxJ30CL	TEL-B27	TEL-B77	SPX-S15W	TEL-B27	TEL-B77
speax23-ZK	TEL-B27	TEL-B77	speaxJ226YCL	TEL-B27	TEL-B77	SPX-S21	TEL-B27	TEL-B77
speax31CL	TEL-B27	TEL-B77	speaxN1CL	TEL-B27	TEL-B77	SPX-S21W	TEL-B27	TEL-B77
speax31CL(D)	TEL-B27	TEL-B77	speaxN2AT	TEL-B27	TEL-B77	SPX-S22	TEL-B27	TEL-B77
speax31CL(Y)	TEL-B27	TEL-B77	speaxN2WCL	TEL-B27	TEL-B77	SPX-S22W	TEL-B27	TEL-B77
speax31CLW	TEL-B27	TEL-B77	speaxN25CL	TEL-B27	TEL-B77	SPX-S30	TEL-B27	TEL-B77
speax31W	TEL-B27	TEL-B77	speaxN26WCL	TEL-B27	TEL-B77	SPX-S30W	TEL-B27	TEL-B77
speax31-ZK	TEL-B27	TEL-B77	speaxN105K	TEL-B27	TEL-B77	SPX-S31(P)	TEL-B27	TEL-B77
speax32CL	TEL-B27	TEL-B77	speaxN205KW	TEL-B27	TEL-B77	SPX-S31(S)	TEL-B27	TEL-B77
speax32CL(Y)	TEL-B27	TEL-B77	speax-ZK6	TEL-B27	TEL-B77	SPX-S31W	TEL-B27	TEL-B77
speax32CL-H	TEL-B27	TEL-B77	speax-ZK7	TEL-B27	TEL-B77	SPX-S32	TEL-B27	TEL-B77
speax32-ZK	TEL-B27	TEL-B77	speax-ZK7H	TEL-B27	TEL-B77	SPX-S32W	TEL-B27	TEL-B77
speax32-ZKH	TEL-B27	TEL-B77	speax-ZK8	TEL-B27	TEL-B77	SPX-S150K	TEL-B27	TEL-B77
speax37CL	TEL-B27	TEL-B77	speax-ZK9	TEL-B27	TEL-B77	SPX-S210K	TEL-B27	TEL-B77
speax37CL(D)	TEL-B27	TEL-B77	speax-ZK10	TEL-B27	TEL-B77	SPX-S217B	TEL-B27	TEL-B77
speax37CLW	TEL-B27	TEL-B77	speax-ZK11	TEL-B27	TEL-B77	SPX-S301Y	TEL-B27	TEL-B77
speax43CL	TEL-B27	TEL-B77	SPL-850	TEL-B27	TEL-B77	SPX-S315V	TEL-B27	TEL-B77
speax43CL(D)	TEL-B27	TEL-B77	SPL-850W	TEL-B27	TEL-B77	SP-ZD50	TEL-B35	TEL-B85
speax43CLW	TEL-B27	TEL-B77	SPL-N10	TEL-B27	TEL-B77	SP-ZD51	TEL-B35	TEL-B85
speax45CL	TEL-B27	TEL-B77	SPL-N11W	TEL-B27	TEL-B77	SP-ZK12	TEL-B27	TEL-B77
speax45CL-H	TEL-B27	TEL-B77	SPL-N20C	TEL-B27	TEL-B77	SP-ZK20	TEL-B27	TEL-B77
speax45CLW	TEL-B27	TEL-B77	SPL-S50	TEL-B27	TEL-B77	SP-ZK30	TEL-B27	TEL-B77
speax45CLW-H	TEL-B27	TEL-B77	SPL-S50W	TEL-B27	TEL-B77	SP-ZK40	TEL-B34	TEL-B84
speax52CL	TEL-B27	TEL-B77	SPL-S505V	TEL-B27	TEL-B77			

電話機・FAX メーカー	メーカー充電電池 型番／部品番号	◎型番		
		長持ちタイプ	高容量タイプ	
シャープ	A-002	TEL-B29	TEL-B79	
	M-003	TEL-B33	TEL-B83	
	M-224 ※		TEL-B90	
	N-141	TEL-B25	TEL-B75	
	N-153		TEL-B71	
	UBATN0153AFZZ		TEL-B71	
	UX-BTK1	TEL-B25	TEL-B75	
	BP-T50	TEL-B27	TEL-B77	
	BP2R4V-600	TEL-B23	TEL-B73	
	BP2R4V-600N	TEL-B23	TEL-B73	
日立	BP2R4V-700	TEL-B26	TEL-B76	
	BT76228A	TEL-B28	TEL-B78	
パナソニック	BT76228B	TEL-B28	TEL-B78	
	BTA005AE	TEL-B26	TEL-B76	
	BTA021AE	TEL-B26	TEL-B76	
	HHR05TA3A12	TEL-B28	TEL-B78	
	HHR-TA3/1BA1	TEL-B28	TEL-B78	
	KX-AN34		TEL-B71	
	KX-AN34H		TEL-B71	
	KX-FAN37	TEL-B22	TEL-B72	
	KX-FAN39	TEL-B30	TEL-B80	
	KX-FAN50	TEL-B31	TEL-B81	
	KX-FAN51	TEL-B37	TEL-B87	
	KX-FAN52		TEL-B82	
	KX-FAN55	TEL-B38	TEL-B88	
	KX-FAN57	TEL-B39	TEL-B89	
	P-AA23/1BA01		TEL-B71	
	P-AA42/1BA01	TEL-B26	TEL-B76	
	UG-4403	TEL-B26	TEL-B76	
	UG-4405	TEL-B28	TEL-B78	
	パイオニア	FEX1048	TEL-B23	TEL-B73
		FEX1049	TEL-B23	TEL-B73
FEX1056		TEL-B23	TEL-B73	
FEX1065		TEL-B25	TEL-B75	
FEX1069		TEL-B23	TEL-B73	
FEX1070		TEL-B25	TEL-B75	
FEX1072		TEL-B23	TEL-B73	
FEX1073		TEL-B25	TEL-B75	
FEX1079		TEL-B30	TEL-B80	
FEX1080		TEL-B30	TEL-B80	
TF-BT07		TEL-B23	TEL-B73	
TF-BT09		TEL-B25	TEL-B75	
TF-BT10		TEL-B30	TEL-B80	
TF-BT20		TEL-B34	TEL-B84	
TF-BT22	TEL-B34	TEL-B84		

※シャープ M-224 互換 TEL-B90 は純正電池と同じ 500mAh となります。

電話機・FAX メーカー	メーカー充電電池 型番／部品番号	◎型番	
		長持ちタイプ	高容量タイプ
サンヨー	NNT-14	TEL-B24	TEL-B74
	NNT-200	TEL-B36	TEL-B86
	TEL-BT200	TEL-B36	TEL-B86
NTT	CT-電池パック-033	TEL-B26	TEL-B76
	CT-電池パック-062	TEL-B29	TEL-B79
	CT-電池パック-064		TEL-B71
	CT-電池パック-074	TEL-B25	TEL-B75
	CT-電池パック-077	TEL-B28	TEL-B78
	CT-電池パック-078	TEL-B22	TEL-B72
	CT-電池パック-080	TEL-B25	TEL-B75
	CT-電池パック-085	TEL-B31	TEL-B81
	CT-電池パック-086	TEL-B33	TEL-B83
	CT-電池パック-087	TEL-B33	TEL-B83
	CT-電池パック-092	TEL-B37	TEL-B87
	CT-電池パック-093	TEL-B30	TEL-B80
	CT-電池パック-096		TEL-B82
	CT-電池パック-098	TEL-B29	TEL-B79
	CT-電池パック-099	TEL-B35	TEL-B85
CT-電池パック-107	TEL-B29	TEL-B79	
CT-電池パック-108	TEL-B38	TEL-B88	
ユニデン	BT-794	TEL-B34	TEL-B84
	BT-862	TEL-B34	TEL-B84
	UXB1	TEL-B27	TEL-B77
	UXB2	TEL-B27	TEL-B77
ブラザー	BCL-BT	TEL-B25	TEL-B75
	BCL-BT30	TEL-B30	TEL-B80
キヤノン	DBT100	TEL-B28	TEL-B78
	HBT100	TEL-B27	TEL-B77
	HBT200	TEL-B27	TEL-B77
	HBT300	TEL-B27	TEL-B77
	HBT500	TEL-B33	TEL-B83
東芝	本体型番からお探してください	TEL-B25	TEL-B75
	NB-R24	TEL-B27	TEL-B77
NEC	NB-R24M	TEL-B27	TEL-B77
	NB-R24S	TEL-B27	TEL-B77
	NB-R24SK	TEL-B27	TEL-B77
	SP-D3	TEL-B35	TEL-B85
	SP-N1	TEL-B27	TEL-B77
	SP-N2	TEL-B34	TEL-B84