



POLYSTEEL 600

For Product Information
visit www.COASTportland.com

商品の仕様はCOASTのウェブサイト
@www.COASTportland.com
をご覧ください。

POLYSTEEL 600 INSTRUCTIONS:

BATTERY INSTALLATION:

Turn the tail cap in a counterclockwise direction to remove the cap.

Remove the battery cartridge.

Place four AA batteries into the cartridge in the direction indicated in the center of the cartridge.

Replace the cartridge in the light in the direction indicated by the arrow on the cartridge.

Replace the tail cap and turn it clockwise to tighten it until it is completely closed.

Note: The POLYSTEEL 600 in clam pack packaging comes with batteries pre-installed.

QUICK CYCLE SWITCH OPERATION:

This flashlight is equipped with COAST's Quick-Cycle Switch, featuring high, medium and low beams.

To activate the high mode from the off position, press the on/off switch until it clicks once, then releases. Press the on/off switch until it clicks a second time to turn off the light.

To activate the medium mode, press the on/off switch until it clicks a third time, then release. Press the on/off switch until it clicks a fourth time to turn off the light.

To activate the low mode, press the on/off switch until it clicks a fifth time, then release. Press the on/off switch until it clicks a sixth time to turn off the light.

The light can also be operated in "momentary" mode. Momentary mode is activated by partially depressing the on/off switch (less pressure than required for a full click). The momentary switch will cycle the light through the high, medium, and low beam modes.

Any time the light is turned off for more than five seconds, the high/medium/low cycle will reset, and the high beam will be activated when the light is turned back on.

PURE BEAM FOCUSING OPTIC:

This flashlight is equipped with COAST's Pure Beam Focusing Optic that allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot beam for long distance illumination.

To adjust the beam into the Bulls-Eye Spot mode, turn the front bezel of the light clockwise.

To change the beam into the flood light mode, turn the front bezel of the light counterclockwise.

MAINTENANCE:

The POLYSTEEL 600 is rated IPX8 and submersible to 3 meters for 6 hours. Wipe the external body with a cloth moistened with water or isopropyl.

POLYSTEEL 600取扱説明書:

電池の取り付け:

後部キャップを反時計方向に回して取り外します。

バッテリーカートリッジを取り出します。

カートリッジ上の矢印が示す方向に沿って、カートリッジの中央に4本の単3形乾電池を挿入します。

カートリッジ上の矢印の方向に沿って、カートリッジを本体に差し込みます。

後部キャップを戻し、完全に締まるまで時計回りに回します。

注: POLYSTEEL 600は、電池があらかじめ装着された状態で出荷されています。

「クイック・サイクル・スイッチ」の操作:

このフラッシュライトでは、ハイビーム、ミディアムビーム、ロービームを切り替えることができる。COAST独自の「クイック・サイクル・スイッチ」を装備しています。

OFFの状態からハイビームをONにするには、ON/OFFスイッチを1度だけカチッとすることで押し、指を離します。ライトをOFFにするには、ON/OFFスイッチを再度カチッとすることで押しします。

ミディアムビームをONにするには、ON/OFFスイッチを3回カチッとすることで押しして指を離します。ライトをOFFにするには、ON/OFFスイッチを再度カチッとすることで押しします。

ロービームをONにするには、ON/OFFスイッチを5回カチッとすることで押しして指を離します。ライトをOFFにするには、ON/OFFスイッチを再度カチッとすることで押しします。

ライトを「半押し」モードで点灯させることもできます。「半押し」モードでは、ON/OFFスイッチを半押し(カチッとすると手前で止めた)状態で使用します。このモードでスイッチを動作させると、ハイビーム、ミディアムビーム、ロービームが交互に切り替わります。

ライトを5秒以上OFFにすると、ハイビーム、ミディアムビーム、ロービームの切替サイクルがリセットされます。その後再びONにすると、最初はハイビームが点灯します。

ビュア・ビーム範囲調節システム:

このフラッシュライトは、COASTの「ビュア・ビーム範囲調節システム」を備えています。この機構により、広範囲を照射するビームと、範囲を絞ることで長距離まで届く「ブルズアイ・スポット・ビーム」に切り替えることができます。

ビームを「ブルズアイ・スポット・ビーム」に切り替えるには、ライトの前方ベゼルを時計方向に回します。

ビームの照射範囲を広くするには、ライトの前方ベゼルを反時計方向に回します。

メンテナンス:

POLYSTEEL 600はIPX8基準を満たしており、水深3メートルで6時間使用することができます。メンテナンスの際は、水やイソプロピルで濡らせた布で、本体の外側を拭いてください。

警告

- 光をのぞきこんだり、ほかの人の目に当てたりしない。
- 底蓋をしっかり締めて使用する。しっかり締めていないと防水性能が失われてしまいます。
- 本体が濡れている状態で電池交換をしない。必ず本体の水気をふき取り、乾いた場所で電池交換をしてください。
- 本品を分解したり改造したりしない。
- 古い乾電池と新しい乾電池、または異種の乾電池を同時に使用しない。乾電池の発熱・破裂・液もれの原因となります。
- 電池交換の際は、全本数同時に交換する。

注意

- 白色系LEDは多少色のバラつきが出る場合があります。
- LEDは交換できません。
- 以下のことを守らないと、電池の液もれなどの原因となります。
 - 電池の仕様表示に従って正しく使用する。
 - 乾電池は必ずⓐを本品に正しく使用する。
 - 定期的に点灯、点検をする。
 - 使い切った乾電池はすぐに本体から取り出す。
 - 電池の容量が少なくなると、LED球にチャージがでます。
 - 電池をお取替えください。
 - オキシライド系乾電池のように初期電圧の高い電池のご使用はお避け下さい。故障の原因となります。(オキシライドはバナニウム(Ⅱ)の登録商標です。)

※注意 海水につけたあとは真水に1時間ほど浸してください。錆防止もしくは低減になります。