



# HL7

For Product information  
visit: [www.COASTportland.com](http://www.COASTportland.com)

商品の仕様はCOASTのウェブサイト  
([www.COASTportland.com](http://www.COASTportland.com))  
をご覧ください。

## HL7 INSTRUCTIONS:

### BATTERY INSTALLATION:

The HL7 uses three AAA alkaline batteries. The batteries are housed in the rear of the headlamp.

To access the battery compartment, pull the elastic headband slightly away from the battery pack. Remove the rubber battery case cover by grasping the tab at the top of the cover and pulling it away from the battery pack.

Insert the batteries in the direction indicated inside the battery pack. Replace rubber battery case cover, making sure that the cover is paced evenly over the rim of the case.

### LIGHT OPERATION:

To turn on the light, fully depress the red power switch on top of the light. To turn off the light, depress the red switch on top of the light a second time.

To adjust the brightness, slide the VLT (Variable Light Technology) Dimmer on top of the battery pack. Move to the right to increase the brightness. Move the switch to the left to decrease the brightness.

### FOCUS AND BEAM POSITION ADJUSTMENT:

This headlamp is equipped with COAST's Pure Beam Focusing Optic System with Twist Focus, which allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot beam for long distance illumination. To adjust the beam into flood light mode, rotate the Twist Focus Ring bezel around the lens of the light counterclockwise while wearing the headlamp. To adjust the beam into Bulls-Eye Spot mode, rotate the Twist Focus Ring bezel around the lens of the light clockwise while wearing the headlamp.

The hinged adjustment allows you to tilt the headlamp downward to illuminate close objects. To adjust the tilt position of the headlamp, hold the body of the headlamp with one hand and tilt the body away from the back plate (which retains the strap), holding the back plate with a second hand (if necessary).

### HEAD STRAP ADJUSTMENT:

To adjust the HL7 to fit your head first slide the buckle on the left side of the head strap to adjust the strap to fit the circumference of your head. It may be necessary to slide the head of the light and battery pack on the head strap to center the light once the head band is adjusted to the proper size.

Then, adjust the top strap by sliding the buckle forward or back.

### HARD HAT SAFETY HELMET CLIP USE:

The HL7 includes helmet clips for use with hard hat style safety helmets. To use the helmet clips, loosen the side of the headband to fit the helmet and attach the clips to the side strap of the headlamp, evenly spaced with two on each side.

Note: One of the clips has a wider loop to fit over the area on the side headband where the Z cord is located. Put the headlamp on the safety helmet and attach the clips to the rim of the helmet. Some adjustment of the clip positions and head straps will be necessary for proper fit on safety helmets.

Note: Clips are designed for use ONLY with HARD HAT style safety helmets. They are not acceptable for use on most sporting safety helmets.

### MAINTENANCE:

Wipe the external body with a cloth moistened with water or isopropyl alcohol. Allow to dry before use. Do not submerge.

## HL7 使用ガイド:

### 電池の取り付け:

HL7 では、3本の単4形アルカリ乾電池を使用します。電池はヘッドランプの背面に挿入します。

電池ボックスのカバーを開けるにはまず、ベルトをゆるめ、ゴム製の電池ボックスカバーを外してください。単4形乾電池3本を電池ボックス内側に印された方向に挿入します。ゴム製の電池ボックスカバーをしっかりと電池ボックスに押さえつけながらしっかり閉じます。

古い電池と新しい電池を混ぜて使用しないでください。長期保管の場合は必ず電池を取り外してから保管してください。

### ライトの操作:

ライトを ON にするには、ライト上の赤い電源スイッチを押します。ライトを OFF にするには、ライトの上にある赤色のスイッチを再度押します。

明るさを調節するには、電池ボックスの上にある VLT (Variable Light Technology : 調光技術) 照明調節スイッチをスライドさせます。輝度を上げるには、右に動かします。輝度を下げるには、スイッチを左に動かします。

### 焦点とビーム位置の調整:

このヘッドランプは、COAST 独自の「ツイストフォーカス搭載集光光学系ビュア・ビーム」を備えています。この機能により、広範囲を照射するビームと、範囲を絞ることで長距離まで届く「ブルズアイ・スポット・ビーム」を切り替えることができます。広範囲モードに切り替えるには、ヘッドランプを装着している状態で、レンズの周りにあるツイスト・フォーカス・リングのベゼルを反時計回りに回転させます。「ブルズアイ・スポット・ビーム」モードに切り替えるには、ヘッドランプを装着している状態で、レンズの周りにあるツイスト・フォーカス・リングのベゼルを時計回りに回転させます。

照射角度調整機構により、近くにある物体を照らす際ヘッドランプを下側に傾けることができます。ヘッドランプのチルト位置を調整するには、片手でヘッドランプの本体を押さながら、(ストラップを挟む) バックプレートから離すようにして本体を傾けます。その際に、必要であれば他方の手でバックプレートを押さえてください。

### ヘッドストラップの調整:

頭に合わせて HL7 を調整するには、まず、ヘッドストラップの左側面にあるバックルをスライドさせてストラップを調整します。ヘッドバンドを最適なサイズに調整した後は、ヘッドストラップ上でヘッドライトや電池/バックの位置を中央にスライドさせます。

そして、バックルを前後にスライドさせてトップストラップを調整します。

### ヘルメット取付用安全クリップの使用:

HL7 には、ハードシェルの保護ヘルメットに取り付けるためのヘルメット取付用クリップが同梱されています。ヘルメットクリップを使用するには、ヘッドバンドの側面を緩めてヘルメットに巻き付けます。ヘッドランプのサイドストラップに片側2個のクリップを取り付け、間隔が均等になるように調整します。

注: クリップの1つは、Z コードのある側のヘッドバンドの領域に合わせた幅広ループになっています。ヘッドランプを保護ヘルメットに取り付け、ヘルメットの縁にクリップを取り付けます。保護ヘルメットに正しく装着するには、クリップの位置とヘッドストラップを調整します。

注: クリップは、ハードシェルの保護ヘルメットで使用するのみを想定しています。大部分のスポーツ用ヘルメットでは、使用に適しません。

### メンテナンス:

水またはイソプロピルアルコールで湿らせた布で、本体の外側を拭いてください。乾くまでは使用を控えてください。絶対に水に浸けしないでください。

### 警告

- 光をのぞきこんだり、ほかの人の目に当てたりしない。
- 本品は水中用ではないので、水中で使用しない。
- 電池蓋は必ずしっかりと閉じる。閉じていないと防水性能が損なわれます。
- 本品に衝撃を与えたり、無理な力を加えない。
- 本品を分解したり改造したりしない。
- 古い乾電池と新しい乾電池、または真種の乾電池を同時に使用しない。
- 乾電池の発熱・破裂・液もれの原因となります。
- 電池交換の際は、全本数同時に交換する。

### 注意

- LEDの特性上、光の色や明るさにバラつきが出る場合がありますので、ご了承ください。
- LEDは交換できません。
- 以下のことを守らないと、電池の液漏れなどの原因となります。
- 電池の仕様表示に従って正しく使用する。 ○ 乾電池は必ず⊕⊖を本品に正しく使用する。 ○ 定期的に点灯、点検をする。 ○ 使い切った乾電池はすぐに電池ボックスから取り出す。 ○ 電池の容量が少なくなると、LED球にチラツキがでます。電池をお取替ください。 ○ オキシライド系乾電池のように初期電圧の高い電池のご使用はお避け下さい。故障の原因となります。(オキシライドはバナニョニック®の登録商標です。)

# 保証書

## 保証規定

## 無料修理規定

- 取扱説明書、本体貼付ラベルなどの注意書に従った使用状態で、保証期間内に故障した場合のみ無料修理いたします。
- 保証期間中でも次の場合には有料修理となります。
  - (イ) 使用上の誤りまたは、自己修理、分解、調整、改造などによる故障及び損傷
  - (ロ) お買い上げ後の輸送、移動、落下などによる故障及び損傷
  - (ハ) 火災、地震、水害、落雷、その他の天災地変、公害、塩害、異常電圧などによる故障及び損傷
  - (ニ) 消耗または摩耗した部品、付属品の交換
  - (ホ) 本書のご提示がない場合
  - (ヘ) 本書にお買い上げ年月日、お客様名、販売店名の記入がない場合あるいは文字を書きかえられた場合  
(但し、販売シールや領収書でも未記入項目の代用となります。)
  - (ト) 本品本来の用途以外に使用された場合の故障及び損傷
  - (チ) 一般家庭用以外 (例：業務用、または業務に準ずる使用方法) で使用された場合の故障及び損傷
- ご贈答、ご転居などで本保証書に記載のお買い上げ販売店に修理をご依頼に出来ない場合は、弊社修理ご相談センターにお問い合わせください。
- 本書は日本国内においてのみ有効です。 This warranty is valid only in Japan.
- 本書は再発行いたしませんので紛失しないように大切に保管してください。

|               |            |                       |  |
|---------------|------------|-----------------------|--|
| 商品名 COAST HL7 |            | ★お買い上げ日：              |  |
| 型番：HL7        |            | 年 月 日                 |  |
| 品番：07-8756    |            | 保証期間：本体3年間(お買い上げの日から) |  |
| お客様           | お名前 様      |                       |  |
|               | ご住所 (〒 - ) |                       |  |
| 電話 ( )        |            |                       |  |
| 修理メモ          |            |                       |  |
| 販売店           | ★住所 店名 電話  |                       |  |
| 印             |            |                       |  |

(注) ★印欄にお買い上げ日と販売店の記入がない場合は無効となりますので、必ずご確認ください。

※この保証書は、本書に明示した期間、条件のもとにおいて無料修理をお約束するものです。

※この保証書によって保証書を発行している者（保証責任者）、及びそれ以外の事業者に対するお客様の法律上の権利を制限するものではありません。

※保証期間経過後の修理についてご不明な場合は、お買い上げの販売店または弊社修理ご相談センターにお問い合わせください。

※お客様にご記入いただいた保証書の控えは、保証期間内のサービス活動及びその後の安全点検活動のために記載内容を利用させていただく場合がございますのでご了承ください。

OHM 株式会社 オーム電機  
〒342-8502 埼玉県吉川市旭3-8  
<http://www.ohm-electric.co.jp>

|                       |                                                 |
|-----------------------|-------------------------------------------------|
| 修理に関するご相談は 修理ご相談センターへ |                                                 |
| 電話受付                  | 048-992-3970 平日 9：00～17：00<br>土・日・祝日及び年末年始は除きます |

|                           |                                                  |
|---------------------------|--------------------------------------------------|
| 製品に関するお問い合わせは お客様相談室 へ    |                                                  |
| ●通話料無料                    | ●携帯・IP・公衆電話からは                                   |
| 0120-963-006 048-992-2735 |                                                  |
| 電話受付                      | 平日 9：00～17：30 土曜 9：00～17：00<br>※日曜・祝日及び年末年始は除きます |